




Front expansion header




Mid expansion header





Debug header




User interface




Motors and encoders



Line (reflectance) sensors



Bump sensors



Inertial sensors

