










Pin Port







SPI2 SPI1




USART3




QUADSPI




I2C2 I2C1




I2S3 I2S2




SDMMC




CAN1




CAN2




SAI_A SAI_B




UART1




USB HS ULPI




ETH




USER LED




Joystick




NAND FLASH




DCMI



WakeUp Button



LCD 4.3inch



LCD 7inch

