





USB




Thermal USB Camera

Type_C1




D11
D31
D41



R4
R5
RST




C2
C3



X1

C14
R2

R3
R15



P1



C8
FB1
C9
C10

FPC1



