

LoRa-E5

LoRa Wireless Module - Powered by STM32WE5

AT Command Specification

V1.0

Content

1 Introduction.....	8
1.1 Feature.....	8
1.2 Related Products.....	9
2 Preface	10
2.1 Conventions	10
2.2 Symbols	10
2.3 Format.....	10
2.3.1 Query.....	10
2.3.2 Configure / Control.....	10
2.3.3 Return.....	10
2.4 Error.....	10
2.5 EEPROM.....	11
3 Band Plans	12
3.1 Data Rate Scheme	12
3.2 Payload Length Limitation	13
3.3 TX Output Power Encoding	13
3.4 Channels.....	14
3.4.1 Default Uplink Channels.....	14
3.4.2 Downlink RXWIN1 Channels	15
3.4.3 Downlink RXWIN2 Channel	15
3.4.4 Join Request Channels.....	15
3.5 Join Duty Cycle Limitation	16
3.6 RX1DROffset Limitation	16
3.6.1 EU868/EU434/CN470 /KR920/RU864/CN470PREQUEL/STE920.....	16
3.6.2 US915/ US915HYBRID/AU915.....	16
3.6.3 AS923.....	16
3.6.4 IN865.....	17
3.7 CFLIST.....	17
3.7.1 Type 0x00.....	17
3.7.2 Type 0x01	17
3.8 LinkAdrReq	17
3.9 Band Specific Limitation	18

3.9.1 US915/AU915/CN470 Channel Limitation.....	18
3.9.2 EU868 Duty Cycle Limitation	18
3.9.3 CN799 Duty Cycle Limitation	18
3.9.1 EU433 Duty Cycle Limitation	18
3.9.2 AS923 Dwell Time Limitation	18
3.9.3 KR920 Channels and TX Power Limitation	19
3.10 Band Frequency Range.....	19
3.10.1 AS923 Region Limitation.....	19
3.11 Class B.....	20
3.11.1 Default Parameters	20
3.11.2 Beacon Frame Content	21
3.11.3 Periodicity	21
4 Commands	22
4.1 AT	24
4.2 VER.....	24
4.3 ID	24
4.4 RESET	25
4.5 MSG.....	25
4.5.1 LinkCheckReq	25
4.5.2 Error Status.....	26
4.6 CMSG	26
4.7 MSGHEX.....	27
4.7.1 Send Unconfirmed Message with Zero Length Payload.....	27
4.8 CMSGHEX.....	27
4.8.1 Send Confirmed Message with Zero Length Payload.....	28
4.9 PMSG	28
4.10 PMSGHEX	28
4.11 PORT	28
4.12 ADR	29
4.13 DR.....	29
4.13.1 Check and Set Data Rate	29
4.13.2 Data Rate Scheme.....	29
4.14 CH.....	30

4.14.1 Query Channel Configuration.....	30
4.14.2 Add or Delete Channel.....	30
4.14.3 Enable or Disable Channel	31
4.15 POWER.....	31
4.15.1 Set and Check Power	31
4.15.2 Force Set Power	31
4.15.3 Power Table.....	31
4.16 REPT	31
4.17 RETRY	32
4.18 RXWIN2	32
4.19 RXWIN1	32
4.20 KEY.....	33
4.21 FDEFAULT.....	34
4.22 DFU.....	34
4.23 MODE	35
4.24 JOIN.....	35
4.24.1 Specified Data Rate Join.....	36
4.24.2 Auto Join.....	36
4.25 BEACON	37
4.25.1 AT+BEACON	37
4.25.2 AT+BEACON=DMMUL	37
4.25.3 AT+BEACON=INFO	38
4.25.4 AT+BEACON=GWGPS	38
4.25.5 Switch to Class B mode	38
4.26 CLASS	39
4.26.1 Force Save Class Mode.....	40
4.26.2 Class C Downlink.....	40
4.26.3 Class B Downlink	40
4.26.4 Class B Status	40
4.27 DELAY	40
4.28 LW.....	41
4.28.1 CDR.....	41
4.28.2 ULDL	41

4.28.3 DC	42
4.28.4 NET	43
4.28.5 MC	43
4.28.6 THLD	43
4.28.7 BAT	43
4.28.8 TPS	44
4.28.9 SCR	44
4.28.10 JDC	44
4.28.11 CT	45
4.28.12 LEN	45
4.28.13 VER	45
4.28.14 DTR	46
4.28.15 LCR	46
4.28.16 LDRO	46
4.28.17 DCMRX	47
4.28.18 DUMRX	47
4.28.19 AFPACK	48
4.28.20 CHRFB	48
4.29 WDT	48
4.30 LOWPOWER	48
4.30.1 Low Power Auto Mode	49
4.31 VDD	50
4.32 TEMP	50
4.33 RTC	50
4.33.1 Time Synchronization	51
4.33.2 Leap second	51
4.33.3 Time Zone	51
4.34 EEPROM	52
4.35 UART	52
4.35.1 TIMEOUT	52
4.35.2 BR	52
4.36 TEST	53
4.36.1 Help Information	53

4.36.2 Enter TEST mode	53
4.36.3 Query RF configuration	53
4.36.4 Set RF Configuration	54
4.36.5 TX LoRa Packet.....	55
4.36.6 RX LoRa Packet	55
4.36.7 TX Continuous Wave	56
4.36.8 TX Continuous LoRa.....	56
4.36.9 RSSI	56
4.36.10 LWDL.....	56
4.36.1 Beacon Sniffer	56
4.37 LOG	57
Revision.....	58

Tables

Table 1-1 Related products list	9
Table 2-1 Error code list.....	11
Table 2-2 Memorized configuration.....	11
Table 3-1 Data Rate Scheme.....	12
Table 3-2 RF Modulation Bit Rate	12
Table 3-3 Data Rate and Payload Length Map	13
Table 3-4 TX Power Table	14
Table 3-5 Default MaxEIRP Value and MaxEIRP Index Map	14
Table 3-6 MaxEIRP Table.....	14
Table 3-7 Default Uplink Channels.....	14
Table 3-8 Default Downlink RXWIN1 Channels	15
Table 3-9 Default RXWIN2 Configuration.....	15
Table 3-10 Join Request Channels	16
Table 3-11 Join Duty Cycle	16
Table 3-12 RX1DROffset Range.....	16
Table 3-13 AS923 RX1DROffset Effective Table	17
Table 3-14 IN865 RX1DROffset Effective Table	17
Table 3-15 CFList Definition.....	17
Table 3-16 LinkAdrReq ChMaskCntl Definition	18
Table 3-17 ETSI EU868 Regulation	18
Table 3-18 CN779 Duty Cycle Limitation	18
Table 3-19 EU433 Duty Cycle Limitation.....	18
Table 3-20 AS923 Dwell Time Limitation	19
Table 3-21 KR920 Channel and TX power limitation.....	19
Table 3-22 Band Frequency Range	19
Table 3-23 AS923 Region Limitation.....	20
Table 3-24 Class B Default Parameters	20
Table 3-25 Beacon Format	21
Table 3-26 Legacy EU868 and US915 Beacon Format.....	21
Table 3-27 Class B Periodicity Table	21
Table 4-1 Command List.....	22
Table 4-2 Factory default configuration.....	34
Table 4-3 LoRaWAN Delay Items	41
Table 4-4 Duty Cycle Control	42
Table 4-5 TEST mode sub-command list.....	53
Table 4-6 MAX output power of HF and LF band.....	54

1 Introduction

LoRa-E5 is a low-cost, ultra-low power, ultra-small size LoRaWAN® module designed by Seeed Technology Co., Ltd. The module uses ST system-level package chip STM32WLE5JC, embedded high-performance LoRa® chip SX126X and ultra-low power Consumption of MCU.

This document is intended to describe a command interface implementation of LoRaWAN Class A/B/C protocol. LoRaWAN protocol is available from LoRa Alliance, it is recommended to review LoRaWAN specification before using LoRaWAN modem.

1.1 Feature

- Single firmware with multiple bands support
 - Standard LoRaWAN band plan:
 - ◆ EU868 US915 CN779 EU433 AU915 CN470 AS923 KR920 IN865 RU864
 - ◆ US915HYBRID AU915OLD
 - User defined band plan:
 - ◆ CN470PREQUEL STE920 JP920¹
- LoRaWAN Class A/B/C full support
- All LoRaWAN 1.0.x Class A/B/C MAC command:
 - LinkCheckReq / LinkCheckAns
 - LinkADRReq / LinkADRAns
 - DutyCycleReq / DutyCycleAns
 - RXParamSetupReq / RXParamSetupAns
 - DevStatusReq / DevStatusAns
 - NewChannelReq / NewChannelAns
 - RXTimingSetupReq / RXTimingSetupAns
 - TxParamSetupReq / TxParamSetupAns
 - DChannelReq / DChannelAns
 - DeviceTimeReq / DeviceTimeAns
 - PingSlotInfoReq / PingSlotInfoAns
 - PingSlotChannelReq / PingSlotChannelAns
 - BeaconTimingReq / BeaconTimingAns
 - BeaconFreqReq / BeaconFreqAns
- LoRaWAN dynamic select Port Zero / FOpts to send uplink MAC command
- Flexible RXWIN2 configuration interface
- Configurable RXWIN1 channel frequency
- Possibility to enable full-duplex LoRaWAN system
- Maximum configurable 96 channels
- Maximum 255 bytes RF frame
- User configuration nonvolatile

¹ JP920 is backward compatible with AS923 but with customized for Japan market, thus this document will not describe in detail, user can use JP920 the same as AS923.

- Numerous test commands (LoRa P2P, Class C downlink, Continuous Wave etc.)
- Flexible hexadecimal string parser
- Ultra-low power (1.4uA@3.3V 1.9uA@3.3 watchdog on)², intelligent auto low power mode
- Case insensitive commands
- 256 bytes EEPROM to save user data
- RTC time and supply voltage measurement
- Power supply measurement
- AT+LOG to speed up development debugging
- Intelligent LoRaWAN beacon time auto correction
- Multicast for Class B and Class C mode
- Configurable leap seconds through AT command

1.2 Related Products

Part Number	Bootloader	Interface
LoRa-E5-LF	UART	UART
LoRa-E5-HF	UART	UART

Table 1-1 Related products list

² UART interface modem only

2 Preface

2.1 Conventions

- Command is case insensitive;
- All commands have response;
- Command length never exceeds total 528 characters;
- One valid AT Command must end with '\n', "\r\n" is also valid;
- If command timeout feature is enabled, end '\n' will not be mandatory;
- <LF> means the newline character. <CR> means carriage return;
- Default UART configuration "9600, 8, n,1" (8 bits data, no parity, 1 stop bit);

2.2 Symbols

- = --> Set value for command
- ? --> Query
- : --> Start a list input parameter
- + --> Prefix of command
- , --> Separator of parameters
- Space --> Empty character, could be used to format command

NOTE: You could use quote sign < " > to force input parameter with space, such as <AT+MSGHEX="AA BB CC DD EE">, then "AA BB CC DD EE" is treated as one parameter. But if you input command <AT+MSGHEX=AA BB CC DD EE>, "AA BB CC DD EE" will treated as 5 parameters, AT+MSGHEX returns error.

2.3 Format

All commands in this document are end with <CR><LF>. In order to facilitate the description, all <CR><LF> is intentionally omitted in this document.

2.3.1 Query

Use query command to check LoRaWAN modem configuration, such as channel configuration, ADR status, TX power, etc.

AT+COMMAND
AT+COMMAND?
AT+COMMAND=?

NOTE: Query format is available with every LoRaWAN supported command

2.3.2 Configure / Control

Uses configure/control command to set new configuration or control transaction.

AT+COMMAND=DATA

2.3.3 Return

Return data is in format like "+CMD: RETURN DATA"

+COMMAND: "RETURN DATA"

2.4 Error

Code	Comment
-1	Parameters is invalid
-10	Command unknown
-11	Command is in wrong format
-12	Command is unavailable in current mode (Check with "AT+MODE")
-20	Too many parameters. LoRaWAN modem support max 15 parameters
-21	Length of command is too long (exceed 528 bytes)
-22	Receive end symbol timeout, command must end with <LF>
-23	Invalid character received
-24	Either -21, -22 or -23

Table 2-1 Error code list

This error code list applies to all LoRaWAN supported command. User could refer to this list to know what is happening to LoRaWAN modem, when gets errors.

2.5 EEPROM

Items below will be synchronized to EEPROM of LoRaWAN modem once changed successfully, this makes LoRaWAN modem memorized, user doesn't need to reconfigure parameter after repower, LoRaWAN modem helps to keep it. If user wants to go back factory default configuration, refer to 4.21 FDEFAULT.

Item
Channel frequency, datarate range (up to 96 channels)
Datarate
TX power
ADR
RX Window2 frequency/datarate
RX Window1 frequency
Keys(NwkSkey, AppSkey, AppKey)
ID(DevAddr, DevEui, AppEui)
Port
Unconfirmed message repetition
Confirmed message retry
Mode³
LWABP/LWOTAA
Delay(RX1, RX2, JRX1, JRX2)
Multicast parameters (MC_DevAddr, MC_NwkSkey, MC_AppSkey)

Table 2-2 Memorized configuration

³ Test mode is not stored; a reset during test mode makes modem switch back to previous mode.

3 Band Plans

LoRaWAN Class A/B/C AT modem devices support:

LoRaWAN Standard Band Plans:

EU868 US915 US915HYBRID CN779 EU433 AU915 AU915OLD CN470 AS923 KR920 IN865 RU864

Customized band plans:

CN470PREQUEL STE920

Refer to [LoRaWANRegionalParametersv1.0.2_final_1944_1.pdf](#) for details.

3.1 Data Rate Scheme

DR	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	RU864	CN470 PREQUEL	STE920
0	SF12/125	SF10/125	SF10/125	SF12/125	SF12/125	SF12/125	SF10/125	SF12/125	SF12/125	SF12/125	SF12/125	SF12/125	SF12/125	SF12/125
1	SF11/125	SF9/125	SF9/125	SF11/125	SF11/125	SF11/125	SF9/125	SF11/125	SF11/125	SF11/125	SF11/125	SF11/125	SF11/125	SF11/125
2	SF10/125	SF8/125	SF8/125	SF10/125	SF10/125	SF10/125	SF8/125	SF10/125	SF10/125	SF10/125	SF10/125	SF10/125	SF10/125	SF10/125
3	SF9/125	SF7/125	SF7/125	SF9/125	SF9/125	SF9/125	SF7/125	SF9/125	SF9/125	SF9/125	SF9/125	SF9/125	SF9/125	SF9/125
4	SF8/125	SF8/500	SF8/500	SF8/125	SF8/125	SF8/125	SF8/500	SF8/125	SF8/125	SF8/125	SF8/125	SF8/125	SF8/125	SF8/125
5	SF7/125	-	-	SF7/125	SF7/125	SF7/125	-	SF7/125	SF7/125	SF7/125	SF7/125	SF7/125	SF7/125	SF7/125
6	SF7/250	-	-	SF7/250	SF7/250	SF8/500	-	-	SF7/250	-	SF7/250	SF7/250	-	SF7/250
7	FSK	-	-	FSK	FSK	-	-	-	FSK	-	FSK	FSK	-	FSK
8	-	SF12/500	SF12/500	-	-	SF12/500	SF12/500	-	-	-	-	-	-	-
9	-	SF11/500	SF11/500	-	-	SF11/500	SF11/500	-	-	-	-	-	-	-
10	-	SF10/500	SF10/500	-	-	SF10/500	SF10/500	-	-	-	-	-	-	-
11	-	SF9/500	SF9/500	-	-	SF9/500	SF9/500	-	-	-	-	-	-	-
12	-	SF8/500	SF8/500	-	-	SF8/500	SF8/500	-	-	-	-	-	-	-
13	-	SF7/500	SF7/500	-	-	SF7/500	SF7/500	-	-	-	-	-	-	-
14	-	-	-	-	-	-	-	-	-	-	-	-	-	-
15	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Table 3-1 Data Rate Scheme

RF Modulation	Indicative physical bit rate [bit/s]
LoRa SF12/125KHz	250
LoRa SF11/125KHz	440
LoRa SF10/125KHz	980
LoRa SF9/125KHz	1760
LoRa SF8/125KHz	3125
LoRa SF7/125KHz	5470
LoRa SF7/250KHz	11000
FSK 50kbps	50000
LoRa SF12/500KHz	980
LoRa SF11/500KHz	1760
LoRa SF10/500KHz	3900
LoRa SF9/500KHz	7000
LoRa SF8/500KHz	12500
LoRa SF7/500KHz	21900

Table 3-2 RF Modulation Bit Rate

3.2 Payload Length Limitation

Repeater mode is not supported.

D R	EU86 8	US91 5	US915 HYBRI D	CN77 9	EU43 3	AU91 5	AU915OL D	CN47 0	AS92 3	KR92 0	IN86 5	RU86 4	CN470 PREQUE L	STE92 0
0	51	11	11	51	51	51	11	51	51	65	51	51	51	51
1	51	53	53	51	51	51	53	51	51	151	51	51	51	51
2	51	126	126	51	51	51	126	51	51	242	51	51	51	51
3	115	242	242	115	115	115	242	115	115	242	115	115	115	115
4	242	242	242	242	242	242	242	242	242	242	242	242	242	242
5	242	-	-	242	242	242	-	242	242	242	242	242	242	242
6	242	-	-	242	242	242	-	-	242	-	242	242	-	242
7	242	-	-	242	242		-	-	242	-	242	242	-	242
8	-	53	53	-	-	53	53	-	-	-		-	-	-
9	-	129	129	-	-	129	129	-	-	-		-	-	-
10	-	242	242	-	-	242	242	-	-	-		-	-	-
11	-	242	242	-	-	242	242	-	-	-		-	-	-
12	-	242	242	-	-	242	242	-	-	-		-	-	-
13	-	242	242	-	-	242	242	-	-	-		-	-	-
14	-	-	-	-	-		-	-	-	-		-	-	-
15	-	-	-	-	-		-	-	-	-		-	-	-

Table 3-3 Data Rate and Payload Length Map

3.3 TX Output Power Encoding⁴

TXPow er	EU86 8	US91 5	US915 HYBRI D	CN77 9	EU43 3	AU91 5	AU915OL D	CN47 0	AS92 3	KR92 0	IN86 5	RU86 4	CN470 PREQUE L	STE92 0
MaxEIR P	16	30	30	12.15 ₅	12.15	30	30	19.15 ₆	16	14	30	16	19.15	30
0~15	MaxEIRP – 2*TXPower													
0	16	30	30	12	12	30	30	20	16	14	30	16	20	20
1	14	28	28	10	10	28	28	18	14	12	28	14	18	18
2	12	26	26	8	8	26	26	16	12	10	26	12	16	16
3	10	24	24	6	6	24	24	14	10	8	24	10	14	14
4	8	22	22	4	4	22	22	12	8	6	22	8	12	12
5	6	20	20	2	2	20	20	10	6	4	20	6	10	10
6	4	18	18			18	18	8	4	2	18	4	8	8
7	2	16	16			16	16	6	2	0	16	2	6	6
8		14	14			14	14				14			
9		12	12			12	12				12			
10		10	10			10	10				10			
11-15														
TXPow er Max	7	10	10	5	5	10	10	7	7	7	10	7	7	10

⁴ LoRaWAN V1.0.3 US915 / AU915 band supports TxPower maximum 15

⁵ 12.15dBm is set to 12dBm, MaxEIRP Index 2

⁶ 19.15dBm is converted to 20dBm, MaxEIRP Index 7

Default	1	8	8	0	0	8	8	0	0	1	8	0	0	4
---------	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Table 3-4 TX Power Table

	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	RU864	CN470 PREQUEL	STE920
MaxEIRP Index	5	13	13	2	2	13	13	7	5	4	13	5	7	13
MaxEIRP	16	30	30	12.15 ⁷	12.15	30	30	19.15 ⁸	16	14	30	16	19.15	30

Table 3-5 Default MaxEIRP Value and MaxEIRP Index Map

MaxEIRP Index	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
MaxEIRP	8	10	12	13	14	16	18	20	21	24	26	27	29	30	33	36

Table 3-6 MaxEIRP Table

TXPower is defined in LoRaWAN specification Mac command LinkADRReq chapter.

3.4 Channels

3.4.1 Default Uplink Channels

Band \ DR	0	1	2	3-95	Default Data Rate	Channel Numbers	Channel Numbers Max
EU868	868.1 DR0-DR5	868.3 DR0-DR5	868.5 DR0-DR5	-	0	3	16
US915	902.3 DR0-DR3	902.5 DR0-DR3	902.7 DR0-DR3	0-63 902.3 + ch * 200000 DR0-DR3 64-71 903.0 + ch * 600000 DR4	0	72	72
US915HYBRID	902.3 DR0-DR3	902.5 DR0-DR3	902.7 DR0-DR3	0-7 902.3 + ch * 200000 DR0-DR3 64 903.0 + ch * 600000 DR4	0	9	72
CN779	779.5 DR0-DR5	779.7 DR0-DR5	779.9 DR0-DR5	-	0	3	16
EU433	433.175 DR0-DR5	433.375 DR0-DR5	433.575 DR0-DR5	-	0	3	16
AU915	915.2 DR0-DR5	915.4 DR0-DR5	915.6 DR0-DR5	0-63 915.2 + ch * 200000 DR0-DR5 64-71 915.9 + ch * 600000 DR6	0	72	72
AU915OLD	915.2 DR0-DR3	915.4 DR0-DR3	915.6 DR0-DR3	0-63 915.2 + ch * 200000 DR0-DR3 64-71 915.9 + ch * 600000 DR4	0	72	72
CN470	470.3 DR0-DR5	470.5 DR0-DR5	470.7 DR0-DR5	200KHz channel space up to 95	0	96	96
AS923	923.2 DR0-DR5	923.4 DR0-DR5	-	-	2	2	16
KR920	922.1 DR0-DR5	922.3 DR0-DR5	922.5 DR0-DR5	-	0	3	16
IN865	865.0625 DR0-DR5	865.4025 DR0-DR5	865.985 DR0-DR5	-	0	3	16
RU864	868.9 DR0-DR5	869.1 DR0-DR5	-	-	0	2	16
CN470PREQUEL	471.5 DR0-DR5	471.7 DR0-DR5	471.9 DR0-DR5	200KHz channel space up to 7	0	8	16
STE920	922.0 DR0-DR5	922.2 DR0-DR5	922.4 DR0-DR5	200KHz channel space up to 7	0	8	16

Table 3-7 Default Uplink Channels

⁷ 12.15dBm is set to 12dBm, MaxEIRP Index 2

⁸ 19.15dBm is converted to 20dBm, MaxEIRP Index 7

3.4.2 Downlink RXWIN1 Channels

Downlink Data Rate is defined by RX1DROffset.

Band \ CH	0-95
EU868	Same as uplink channels
US915	$923.3 + (\text{ch \% } 8) * 0.6$
US915HYBRID	$923.3 + (\text{ch \% } 8) * 0.6$
CN779	Same as uplink channels
EU433	Same as uplink channels
AU915	$923.3 + (\text{ch \% } 8) * 0.6$
AU915OLD	$923.3 + (\text{ch \% } 8) * 0.6$
CN470	$500.3 + (\text{ch \% } 48) * 0.2$
AS923	Same as uplink channels
KR920	Same as uplink channels
IN865	Same as uplink channels
RU864	Same as uplink channels
CN470PREQUEL	Same as uplink channels
STE920	Same as uplink channels

Table 3-8 Default Downlink RXWIN1 Channels

3.4.3 Downlink RXWIN2 Channel

Band\DR	Frequency/MHz	Data Rate
EU868	869.525	DR0
US915	923.3	DR8
US915HYBRID	923.3	DR8
CN779	786	DR0
EU433	434.665	DR0
AU915	923.3	DR8
AU915OLD	923.3	DR8
CN470	505.3	DR0
AS923	923.2	DR2
KR920	921.9	DR0
IN865	866.55	DR2
RU864	869.1	DR0
CN470PREQUEL	471.3	DR3
STE920	923.2	DR0

Table 3-9 Default RXWIN2 Configuration

3.4.4 Join Request Channels

Band	Channels
EU868	0-2
US915	All uplink channels
US915HYBRID	All uplink channels
CN779	0-2
EU433	0-2
AU915	All uplink channels
AU915OLD	All uplink channels
CN470	All uplink channels
AS923	0-1 (Fixed DR2)
KR920	0-2
IN865	0-2
RU864	0-1

CN470PREQUEL	0-7
STE920	0-7

Table 3-10 Join Request Channels

Note: Although the modem supports user to modify the default uplink channels, it does not encourage user to do so. If user need modify the default channels, please make sure gateway and server support the selected channels.

3.5 Join Duty Cycle Limitation

This firmware enables the global JoinReq duty cycle which applies below table⁹.

Time	Range	Transmit time	DutyCycle
Aggregated during the first hour following power-up or reset	$T_0 < t < T_0 + 1$	Transmit time < 36Sec	1%
Aggregated during the next 10 hours	$T_0 + 1 < t < T_0 + 11$	Transmit time < 36Sec	0.1%
After the first 11 hours, aggregated over 24h	$T_0 + 11 + N < t < T_0 + 35 + N$ ($N \geq 0$)	Transmit time < 8.7Sec per 24h	0.01%

Table 3-11 Join Duty Cycle

"AT+LW=JDC, OFF" command could be used to disable the feature if user need to disable the feature.

3.6 RX1DROffset Limitation

RX1DROffset	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	RU864	CN470 PREQUEL	STE920
Min	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Max	5	3	3	5	5	5	3	5	7	5	7	7	5	5

Table 3-12 RX1DROffset Range

Default RX1DROffset of all bands is 0.

3.6.1 EU868/EU433/CN470 /KR920/RU864/CN470PREQUEL/STE920

$$DR = \text{MAX}(\text{UplinkChannelDaraRate} - \text{RX1DROffset}, \text{DR0})$$

3.6.2 US915/ US915HYBRID/AU915

$$DR = \text{MAX}(\text{MIN}(\text{UplinkChannelDaraRate} + 10 - \text{RX1DROffset}, \text{DR13}), \text{DR8})$$

3.6.3 AS923

$$\text{MIN}(5, \text{MAX}(\text{MinDR}, \text{UplinkChannelDaraRate} - \text{Effective_RX1DROffset}))$$

MinDR depends on the DownlinkDwellTime bit sent to the device in the TxParamSetupReq command:

- Case DownlinkDwellTime = 0 (No limit): MinDR = DR0
- Case DownlinkDwellTime = 1 (400ms): MinDR = DR2

RX1DROffset	0	1	2	3	4	5	6	7
Effective_RX1DROffset	0	1	2	3	4	5	-1	-2

⁹ LoRaWAN102-20161012 Page 37

Table 3-13 AS923 RX1DROffset Effective Table

3.6.4 IN865

MIN(5, MAX(0, UplinkChannelDaraRate - Effective_RX1DROffset))

RX1DROffset	0	1	2	3	4	5	6	7
Effective_RX1DROffset	0	1	2	3	4	5	-1	-2

Table 3-14 IN865 RX1DROffset Effective Table

3.7 CFLIST

3.7.1 Type 0x00

LoRaWAN supports to use CFList to add channels for end-node

CFListType (0x00)	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	RU864	CN470 PREQUEL	STE920
ChId	3-7 ¹⁰	N/A	N/A	3-7	3-7	N/A	N/A	N/A	2-6	3-7	3-7	2-6	N/A	N/A

Table 3-15 CFList Definition

3.7.2 Type 0x01

LoRaWAN V1.0.3 US915 / US915 / CN470 supports to use CFLIST to management channel (ChMask).

CFListType (0x00)	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	RU864	CN470 PREQUEL	STE920
ChMask	N/A	0-71	0-71	N/A	N/A	0-71	N/A	0-95	N/A	N/A	N/A	N/A	N/A	N/A

3.8 LinkAdrReq

ChMaskCn tl	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
0	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15
1	RFU	16-31	16-31	RFU	RFU	16-31	16-31	16-31	RFU	RFU	RFU	16-31	RFU
2	RFU	32-47	32-47	RFU	RFU	32-47	32-47	32-47	RFU	RFU	RFU	32-47	RFU
3	RFU	48-63	48-63	RFU	RFU	48-63	48-63	48-63	RFU	RFU	RFU	48-63	RFU
4	RFU	64-71	64-71	RFU	RFU	64-71	64-71	64-79	RFU	RFU	RFU	64-79	RFU
5	RFU	8LSB CHBik 0-7 8MSBs RFU ¹¹	8LSB CHBik 0-7 8MSBs RFU	RFU	RFU	8LSB CHBik 0-7 8MSBs RFU	RFU	80-95	RFU	RFU	RFU	80-95	RFU
6	All On	0-63 on Mask 64-71	0-63 on Mask 64-71	All On	All On	0-63 on Mask 64-71	0-63 on Mask 64-71	All On	All On	All On	All On	All On	All On
7	RFU	0-63 off	0-63 off	RFU	RFU	0-63 off	0-63 off 64-71	RFU	RFU	RFU	RFU	RFU	RFU

¹⁰ Here has some difference from LoRaWAN specification use 4-8 to define, by which it assume first channel has index 1. Seeed device use index 0 for the first channel.

¹¹ LoRaWAN V1.0.3 Only

ChMaskCn tl	EU86 8	US91 5	US915 HYBRI D	CN77 9	EU43 3	AU91 5	AU915OL D	CN47 0	AS92 3	KR92 0	IN86 5	CN470 PREQUE L	STE92 0
		64-71 Mask	64-71 Mask			64-71 Mask	Mask						

Table 3-16 LinkAdrReq ChMaskCntl Definition

3.9 Band Specific Limitation

3.9.1 US915/AU915/CN470 Channel Limitation

Under these modes, up to 72 (US915/AU915) or 96 (CN470) channels could be enabled. All these channels are not configurable with the default channels according to the definition of LoRaWAN 1.0.1. This means below commands will be invalid:

AT+CH=ch, freq, [drmin], [drmax]
AT+RXWIN1=ch, freq

To turn on/off channel, user need to use AT+CH=NUM or AT+CH=ch, ON/OFF command.

3.9.2 EU868 Duty Cycle Limitation

Only EU868 band need enable duty cycle limitation to comply with ETSI [EN300.220] standard. Band and limitation is defined as below.

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g2	863.00 ~ 865.00	14dBm	0.1%	2MHz
g	865.00 ~ 868.00	14dBm	1%	3MHz
g1	868.00 ~ 868.60	14dBm	1%	600KHz
g2	868.70 ~ 869.20	14dBm	0.1%	500KHz
g3	869.40 ~ 869.65	27dBm	10%	250KHz
g4	869.70 ~ 867.00	14dBm	1%	300KHz

Table 3-17 ETSI EU868 Regulation

3.9.3 CN799 Duty Cycle Limitation

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g0	779.00 ~ 787.00	12.15dBm	1%	8MHz

Table 3-18 CN779 Duty Cycle Limitation

3.9.1 EU433 Duty Cycle Limitation

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g0	433.175 ~ 434.665	12.15dBm	1%	1.5MHz

Table 3-19 EU433 Duty Cycle Limitation

3.9.2 AS923 Dwell Time Limitation

UplinkDwellTime, DownlinkDwellTime and MaxEIRP can be set configured through TxParamSetupReq / TxParamSetupAns MAC command.

DR \ DwellTime	UplinkDwellTime 0	UplinkDwellTime 1	DownlinkDwellTime 0	DownlinkDwellTime 1

DR \ DwellTime	UplinkDwellTime 0	UplinkDwellTime 1	DownlinkDwellTime 0	DownlinkDwellTime 1
0	51	N/A	51	N/A
1	51	N/A	51	N/A
2	51	11	51	11
3	115	53	115	53
4	242	125	242	125
5	242	242	242	242
6	242	242	242	242
7	242	242	242	242
8:15	RFU	RFU	RFU	RFU

Table 3-20 AS923 Dwell Time Limitation

3.9.3 KR920 Channels and TX Power Limitation

For KR920 band, only below channels are available.

Channel Frequency	920.9	921.1	921.3	921.5	921.7	921.9	922.1	922.3	922.5	922.7	922.9	923.1	923.3
Maximum EIRP output power	10	10	10	10	10	10	14	14	14	14	14	14	14

Table 3-21 KR920 Channel and TX power limitation

3.10 Band Frequency Range

Band	Start Channels	End Frequency	Band Width
EU868	863	870	7MHz
US915	902	928	26MHz
US915HYBRID	902	928	26MHz
CN779	799	787	8MHz
EU433	433.175	434.665	1.49MHz
AU915	915	928	13MHz
AU915OLD	915	928	13MHz
CN470	470	510	40MHz
AS923	902	928	26MHz
KR920	920.9	923.3	2.4MHz
IN865	865	867	2MHz
CN470PREQUEL	470	510	40MHz
STE920	920	925	26MHz

Table 3-22 Band Frequency Range

3.10.1 AS923 Region Limitation¹²

Country Name	Frequency Range
Brunei	923-925
Cambodia	923-925
Indonesia	923-925
Japan	920-928
Laos	923-925
New Zealand	915-928
Singapore	920-925
Taiwan	922-928
Thailand	920-925

¹² Defined by LoRaWAN 1.0.2 Regional Parameter

Country Name	Frequency Range
Vietnam	920-925

Table 3-23 AS923 Region Limitation

3.11 Class B

3.11.1 Default Parameters

Band	Beacon Channel Number (ChannelNum)	Beacon Channel Frequency / MHz	Beacon Channel DataRate	Beacon Channel SF/BW	Ping Slot Channel Frequency / MHz	Ping Slot Channel Data Rate / MHz
EU868	1	869.525	DR3	SF9/125KHz	869.525	DR3
US915	8	923.3 + ch * 0.6	DR8	SF12/500KHz	923.3 + ch * 0.6	DR8
US915HYBRID	8	923.3 + ch * 0.6	DR8	SF12/500KHz	923.3 + ch * 0.6	DR8
CN779	1	785	DR3	SF9/125KHz	785	DR3
EU433	1	434.665	DR3	SF9/125KHz	434.665	DR3
AU915	8	923.3 + ch * 0.6	DR10	SF10/500KHz	923.3 + ch * 0.6	DR10
AU915OLD	8	923.3 + ch * 0.6	DR10	SF10/500KHz	923.3 + ch * 0.6	DR10
CN470	8	508.3 + ch * 0.2	DR2	SF10/125KHz	508.3 + ch * 0.2	DR2
AS923	1	923.4	DR3	SF9/125KHz	923.4	DR3
KR920	1	923.1	DR3	SF9/125KHz	923.1	DR3
IN865	1	866.55	DR4	SF8/125KHz	866.55	DR4
RU864	1	869.1	DR3	SF8/125KHz	868.9	DR3
CN470PREQUEL	1	473	DR3	SF9/125KHz	473	DR3
STE920	1	923.4	DR3	SF9/125KHz	923.4	DR3

Table 3-24 Class B Default Parameters

Beacon channel index number at specified beacon time can be calculated with formula:

$$\text{ch} = \text{floor}(\text{beacon_time}/\text{beacon_period}) \% \text{ChannelNum}$$

3.11.2 Beacon Frame Content

LoRaWAN V102B and V103:

Band	Size	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	
EU868	17	RFU	Time			CRC		GwSpecific						CRC											
US915	23	RFU			Time			CRC		GwSpecific						RFU		CRC							
CN779	17	RFU	Time			CRC		GwSpecific						CRC											
EU433	17	RFU	Time			CRC		GwSpecific						CRC											
AU915	19	RFU			Time			CRC		GwSpecific						RFU		CRC							
CN470	19	RFU			Time			CRC		GwSpecific						RFU		CRC							
AS923	17	RFU	Time			CRC		GwSpecific						CRC											
KR920	17	RFU	Time			CRC		GwSpecific						CRC											
IN865	19	RFU	Time			CRC		GwSpecific						RFU		CRC									
RU864	17	RFU	Time			CRC		GwSpecific						CRC											

Table 3-25 Beacon Format

LoRaWAN V102 (Time is in UTC epoch format)

Band	Size	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
EU868 V102	17	NetId		Time			CRC		GwSpecific						CRC									
US915 V102	19	NetId		Time			CRC		GwSpecific						RFU		CRC							

Table 3-26 Legacy EU868 and US915 Beacon Format

3.11.3 Periodicity

Periodicity is a very important Class B parameter to control ping slot numbers and ping slot timing. Periodicity is set to 5 by default. **AT+BEACON=periodicity** command can be used to configure periodicity.

Periodicity	Ping slot control	0	1	2	3	4	5	6	7
PingNb	Number of ping slots per beacon period.	128	64	32	16	8	4	2	1
PingPeriod	Period of the device receiver wake-up expressed in number of slots	32	64	128	256	512	1024	2048	4096
PingPeriodTime/s	Period of the device receiver wake-up expressed in seconds	0.96	1.92	3.84	7.68	15.36	30.72	61.44	122.88
PingOffset	Randomized offset computed at each beacon period start.	0-31	0-63	0-127	0-255	0-511	0-1023	0-2047	0-4095

Table 3-27 Class B Periodicity Table

4 Commands

Command	Description
AT	Test command
FDEFAULT	Factory data reset
RESET	Software reset
DFU	Force bootloader to enter dfu mode
LOWPOWER	Enter sleep mode
VER	Version[Major.Minor.Patch]
MSG	LoRaWAN unconfirmed data
MSGHEX	LoRaWAN unconfirmed data in hex
CMSG	LoRaWAN confirmed data
CMSGHEX	LoRaWAN confirmed data in hex
PMSG	LoRaWAN proprietary
PMSGHEX	LoRaWAN proprietary in hex
CH	LoRaWAN channel frequency
DR	LoRaWAN datarate
ADR	LoRaWAN ADR control
REPT	Unconfirmed message repetition
RETRY	Confirmed message retry
POWER	LoRaWAN TX power
RXWIN2	LoRaWAN RX window2
RXWIN1	LoRaWAN RX window1
PORT	LoRaWAN communication port
MODE	LWABP, LWOTAA, TEST
ID	LoRaWAN DevAddr/DevEui/AppEui
KEY	Set NWKSKEY/APPSKEY/APPKEY
CLASS	Choose LoRaWAN modem class(A/B/C)
JOIN	LoRaWAN OTAA JOIN
LW	LoRaWAN misc configuration (CDR, ULDL, NET, DC, MC, THLD)
BEACON	LoRaWAN Class B utilities
TEST	Send test serious command
UART	UART configure
DELAY	RX window delay
VDD	Get VDD
RTC	RTC time get/set
EEPROM	Write/Read EEPROM
WDT	Watchdog control
TEMP	Get Temperature
LOG	Log DEBUG/INFO/WARN/ERROR/FATAL/PANIC/QUIET

Table 4-1 Command List

4.1 AT

Use to test if connection of module is OK. This is a dummy command just like other common "AT modules"

Format:

AT

Return:

+AT: OK

4.2 VER

Check firmware version. Versioning rule refers to [Semantic Versioning 2.0.0](#).

Format:

AT+VER

Return:

+VER: \$MAJOR.\$MINOR.\$PATCH

+VER: 4.0.11

4.3 ID

Use to check the ID of the LoRaWAN module, or change the ID. ID is treated as big endian numbers.

Read ID Format:

```
AT+ID // Read all, DevAddr(ABP), DevEui(OTAA), AppEui(OTAA)
AT+ID=DevAddr // Read DevAddr
AT+ID=DevEui // Read DevEui
AT+ID=AppEui // Read AppEui
AT+ID=DevAddr, "devaddr" // Set new DevAddr
AT+ID=DevEui, "deveui" // Set new DevEui
AT+ID=AppEui, "appeui" // Set new AppEui
```

Return:

+ID: DevAddr, xx:xx:xx:xx

+ID: DevEui, xx:xx:xx:xx:xx:xx:xx:xx

+ID: AppEui¹³, xx:xx:xx:xx:xx:xx:xx:xx

Change end device address (**DEVADDR**)

AT+ID=DevAddr, "4 bytes length hex identifier"

eg: **AT+ID=DevAddr, "01234567"**

eg: **AT+ID=DEVADDR, "01 23 45 67"**

Return:

+ID: DevAddr, 01:23:45:67

Change device extended unique identifier (**DEVEUI**)

AT+ID= DevEui, "8 bytes length hex identifier (64bits)"

eg: **AT+ID=DevEui, "0123456789ABCDEF"**

eg: **AT+ID=DEVEUI, "01 23 45 67 89 AB CD EF"**

¹³ Default AppEui is 8000000000000006 (IEEE EUI64)

Return:

+ID: DevEui, 01:23:45:67:89:AB:CD:EF

Change device extended unique identifier (**APPEUI**)

AT+ID= AppEui, "8 bytes length hex identifier (64bits)"

eg: **AT+ID=AppEui, "0123456789ABCDEF"**

eg: **AT+ID=APPEUI, "01 23 45 67 89 AB CD EF"**

Return:

+ID: AppEui, 01:23:45:67:89:AB:CD:EF

4.4 RESET

Use to reset the module. If module returns error, then reset function is invalid.

Format:

AT+RESET

Return:

+RESET: OK

4.5 MSG

Use to send string format frame which is no need to be confirmed by the server.

Format:

AT+MSG="Data to send"

Return: *(Full return message)*

+MSG: Start

+MSG: FPENDING

+MSG: Link 20, 1

+MSG: ACK Received

+MSG: MULTICAST

+MSG: PORT: 8; RX: "12345678"

+MSG: RXWIN2¹⁴, RSSI -106, SNR 4

+MSG: Done

Below return messages are optional, it is returned only in the cases that specified event occurs.

+MSG: FPENDING // *Downlink frame FPENDING flag is set*

+MSG: Link 20, 1 // *LinkCheckAns received*

+MSG: ACK Received // *Downlink frame ACK flag is set*

+MSG: MULTICAST // *Downlink frame is multi cast message*

+MSG: PORT: 8; RX: "12345678" // *Downlink message is received*

+MSG: RXWIN2, RSSI -106, SNR 4 // *Downlink frame signal strength*

4.5.1 LinkCheckReq

AT+MSG could be used to send LinkCheckReq mac command to check Link status between modem and server.

¹⁴ **RXWIN2**: Message is received during RX Window2; **RXWIN1**: RX Window1; **RXWIN0**: Class C Extra RXWIN2.

AT+MSG

+MSG: Start

+MSG: TX ""

+MSG: Link 20, 1

+MSG: RXWIN1, RSSI -93, SNR 6.25

+MSG: Done

From example above, the modem returns “**+MSG: Link 20, 1**” to host, it is in the format:

+MSG: Link Margin, GwCnt

The demodulation margin (**Margin**) is an 8-bit unsigned integer in the range of 0..254 indicating the link margin in dB of the last successfully received LinkCheckReq command.

A value of “0” means that the frame was received at the demodulation floor (0 dB or no margin) while a value of “20”, for example, means that the frame reached the gateway 20 dB above the demodulation floor. Value “255” is reserved.

The gateway count (**GwCnt**) is the number of gateways that successfully received the last LinkCheckReq command.

4.5.2 Error Status

1. LoRaWAN transaction service is ongoing
+MSG: LoRaWAN modem is busy
2. LoRaWAN modem is in OTAA mode and not joined a network
+MSG: Please join network first
3. LoRaWAN modem already joined to a network previously
+JOIN: Joined already

Note: use AT+JOIN=FORCE to force join if needed.

4. All configured channels are occupied by others.

+MSG: No free channel -70

Note: use AT+LW=THLD to set a new threshold

5. There is no band available for the moment. The modem must stay silence for a while, because of local regulation rules or Join Request Duty Cycle

+MSG: No band in 13469ms

6. Current DR set data rate is not supported

+MSG: DR error

Note: use AT+DR=dr to set a new datarate

7. Current payload length is too long to send.

+MSG: Length error N

Note: N could be 0 or none zero value, if it returns 0, it means there is a pending Uplink MAC Command must be sent through Port 0. User need send a dummy MSG command "AT+MSG" to flush uplink MAC command.

It is recommended for use to run AT+LW=LEN command to get maximum available payload size. And make sure the next packet payload length is less than the available maximum payload length.

Note: use AT+LW=LEN command to get current available length.

4.6 CMSG

Use to send string format frame which must be confirmed by the server.

Format:

AT+CMSG="Data to send"

Return: (Full return message)

```
+CMSG: Start
+CMSG: Wait ACK
+CMSG: FPENDING
+CMSG: Link 20, 1
+CMSG: ACK Received
+CMSG: MULTICAST
+CMSG: PORT: 8; RX: "12345678"
+CMSG: RXWIN215, RSSI -106, SNR 4
+CMSG: Done
```

Below return messages are optional, it is returned only in the cases that specified event occurs.

```
+CMSG: FPENDING // Downlink frame FPENDING flag is set
+CMSG: Link 20, 1 // LinkCheckAns received
+CMSG: ACK Received // Downlink frame ACK flag is set
+CMSG: MULTICAST // Downlink frame is multi cast message
+CMSG: PORT: 8; RX: "12345678" // Downlink message is received
+CMSG: RXWIN2, RSSI -106, SNR 4 // Downlink frame signal strength
```

4.7 MSGHEX

Use to send hex format frame which is no need to be confirmed by the server.

Format:

```
AT+MSGHEX="xx xx xx xx"
eg: AT+MSGHEX="12345678"
```

Return:

```
+MSGHEX: Start
+MSGHEX: Done
```

For detailed examples, please refer to MSG. MSG and MSGHEX are the same command except payload format.

4.7.1 Send Unconfirmed Message with Zero Length Payload

Format:

```
AT+MSGHEX
eg: AT+MSGHEX
```

Return:

```
+MSGHEX: Start
+MSGHEX: Done
```

4.8 CMSGHEX

Use to send hex format frame which must be confirmed by the server.

Format:

```
AT+CMSGHEX="Data to send"
eg: AT+CMSGHEX="12345678"
```

Return:

¹⁵ **RXWIN2**: Message is received during RX Window2; **RXWIN1**: RX Window1; **RXWIN0**: Class C Extra RXWIN2.

+CMGHEX: Start
+CMGHEX: Wait ACK
+CMGHEX: Done

For detailed examples, please refer to CMGHEX. CMGHEX and CMGHEX are the same command except payload format.

4.8.1 Send Confirmed Message with Zero Length Payload

Format:

AT+CMGHEX
eg: AT+CMGHEX

Return:

+CMGHEX: Start
+CMGHEX: Wait ACK
+CMGHEX: Done

4.9 PMSG

Use to send string format LoRaWAN proprietary frames.

Format:

AT+PMSG="Data to send"
eg: AT+PMSG="This is a string"

Return:

+PMSG: Start
+PMSG: Done

4.10 PMSGHEX

Use to send hex format LoRaWAN proprietary frames.

Format:

AT+PMSGHEX="Data to send"
eg: AT+PMSGHEX="AB CD"

Return:

+PMSGHEX: Start
+PMSGHEX: Done

4.11 PORT

Set PORT number which will be used by MSG/CMGHEX/MSGHEX/CMGHEX command to send message, port number should range from 1 to 255. User should refer to LoRaWAN specification to choose port.

Format:

AT+PORT="port" **// "port" should be 1~255**
eg: AT+PORT=8 **// Set port to 8**
eg: AT+PORT=? **// Check current port**

Return:

+PORT: 8 **// PORT query/set return**

4.12 ADR

Set ADR function of LoRaWAN module.

Format:

```
AT+ADR="state"  
eg: AT+ADR=ON           // Enable ADR function  
AT+ADR=OFF             // Disable ADR function  
AT+ADR=?               // Check current ADR configuration
```

Return:

```
+ADR: ON                // ADR query/set return
```

4.13 DR

Use LoRaWAN defined DRx to set datarate of LoRaWAN AT modem. Refer to **Chapter 3 Band Plans** about the detailed definition of LoRaWAN data rate.

4.13.1 Check and Set Data Rate

Format:

```
AT+DR                  // Check current selected DataRate  
AT+DR=drx             // "drx" should range 0~15
```

Return:

```
+DR: DR0  
+DR: US915 DR0 SF10 BW125K
```

Return: *(ADR is functional)*

```
+DR: DR0 (ADR DR3)  
+DR: US915 DR3 SF7 BW125K  
+DR: US915 DR0 SF10 BW125K
```

4.13.2 Data Rate Scheme

Format:

```
AT+DR=band            // "band" could be band names defined in Chapter 3 Band Plans  
AT+DR=SCHEME         // Check current band
```

Return: *(EU868)*

```
+DR: EU868  
+DR: EU868 DR0 SF12 BW125K  
+DR: EU868 DR1 SF11 BW125K  
+DR: EU868 DR2 SF10 BW125K  
+DR: EU868 DR3 SF9 BW125K  
+DR: EU868 DR4 SF8 BW125K  
+DR: EU868 DR5 SF7 BW125K  
+DR: EU868 DR6 SF7 BW250K  
+DR: EU868 DR7 FSK 50kbps  
+DR: EU868 DR8 RFU  
+DR: EU868 DR9 RFU  
+DR: EU868 DR10 RFU  
+DR: EU868 DR11 RFU  
+DR: EU868 DR12 RFU
```

+DR: EU868 DR13 RFU
+DR: EU868 DR14 RFU
+DR: EU868 DR15 RFU

4.14 CH

4.14.1 Query Channel Configuration

Format:

AT+CH
AT+CH=ch

1. Check single channel frequency
eg: AT+CH=2
+CH: 2,868500000,DR0:DR5

2. Query all channels
AT+CH

Query All Channels Return Format:

**+CH: TOTAL_CHANNEL_NUMBER; LCn,FREQn,DR_MINn,DR_MAXn;
LCy,FREQy,DR_MINy,DR_MAXy; ... LCz,FREQz,DR_MINz,DR_MAXz;**
eg: +CH: 3; 0,868100000,DR0,DR5; 1,868300000,DR0,DR5; 2,868500000,DR0,DR5;

4.14.2 Add or Delete Channel

Set channel parameter of LoRaWAN modem, Set frequency zero to delete one channel.

Format:

AT+CH="chn", ["freq"], ["drmin"], ["drmax"]
// Change the chn channel frequency to "Freq"
// "freq" is in MHz.
// Available "drmin"/"drmax" range DR0 ~ DR15

1. Change channel CH3 frequency to 433.3MHz, datarate DR0~DR5
eg: AT+CH=3, 433.3, DR0, DR5
2. Delete channel CH3
eg: AT+CH=3, 0
3. Change channel CH0 frequency to 433.3MHz,DR7
eg: AT+CH=0, 433.3, DR7
4. Change channel CH3 frequency to 433.7MHz, datarate DR0~DR5
eg: AT+CH=3, 433.7, 0, 5
5. Change channel CH3 frequency to 433.7MHz, datarate DR7
eg: AT+CH=3, 433.7, DR7
6. Change channel CH3 frequency to 433.7MHz, with default datarate DR0~DR5
eg: AT+CH=?
eg: AT+CH=3, 433.7
// It is not recommended to use this command

Return:

+CH: 3,433700000,DR0:DR5
+CH: 3,433700000,DR1

4.14.3 Enable or Disable Channel

Format:

AT+CH=NUM

AT+CH=NUM, chm-chn, ..., chx-chy, chz

1. Check current enabled channels

eg: AT+CH=NUM

+CH: NUM, 0-7, 64

2. Enable and disable channels

eg: AT+CH=NUM, 0-5, 64 // Enable channel 0, 1, 2, 3, 4, 5 and 64, disable all others

+CH: NUM, 0-5, 64

Note: All channels should be controlled by a single command. The command operates all channels (0-95).

3. Enable single channel

eg: AT+CH=chn,ON

4. Disable single channel (channel is just masked, not deleted)

eg: AT+CH=chn,OFF

4.15 POWER

4.15.1 Set and Check Power

LoRaWAN TX power is controlled by internal TX power table, and also decided by hardware. Check TX power table to know what power could support.

Format:

AT+POWER

AT+POWER="pow"

// Change LoRaWAN Tx Power

eg: AT+POWER=14

// Change LoRaWAN AT module TX power to 14dBm

Return:

+POWER: 14

4.15.2 Force Set Power

This command can be used to set a fixed TX power for LoRaWAN modem, it will bypass LoRaWAN TX power table and LinkADDRReq command.

Format:

AT+POWER=pow, FORCE

4.15.3 Power Table

This command can be used to check band specific power table.

Format:

AT+POWER=TABLE

+POWER: 30 28 26 24 22 20 18 16 14 12 10

4.16 REPT

Unconfirmed message repeats times.

Format:

```
AT+REPT="Repeat Times" //Repeat times" should range 1~15  
eg: AT+REPT=2 //Repeat 2 times
```

Return:

```
+REPT: 2
```

4.17 RETRY

Confirmed message retry times. Valid range 0~254, if retry times is less than 2, only one message will be sent. Random delay 3 - 10s between each retry (band duty cycle limitation has the priority)

Format:

```
AT+RETRY="Retry Times" //Retry times" should range 0~15  
eg: AT+RETRY=3 //Retry 2 times (3-1), if no ack receive
```

Return:

```
+RETRY: 3
```

4.18 RXWIN2

Set second RX window frequency and Data Rate. This command will change RXWIN2 configuration, which may cause downlink lost, if configuration is wrong.

Format:

```
AT+ RXWIN2 // Query RX Window2 configuration  
AT+RXWIN2=Frequency,DRx // Set frequency and datarate  
AT+RXWIN2=Frequency,SFx,BW // Set RXWIN2 through SF and BW  
eg: AT+RXWIN2=433.3,DR3 // Set RXWIN2 433.3MHz/DR3  
eg: AT+RXWIN2=433.3,SF7,500 // Set RXWIN2 433.3MHz/SF7/BW500KHz
```

Return:

```
// General data rate  
+RXWIN2: 433300000,DR5  
// Customized RX Window2 data rate with spread factor and band width  
+RXWIN2: 433000000,SF7,BW125K
```

From firmware 1.8.0, RXWIN2 command could support more flexible configuration. Both LoRaWAN defined data rate (combination of spread fraction and band width) and LoRa defined spread factor and band width format are supported. User could set his RXWIN2 to any possible SF and BW scheme, which is a very useful function for LoRaWAN proof of concept.

4.19 RXWIN1

RXWIN1 command could be used to set customized RXWIN channel, each RXWIN channel maps to an uplink channel. When RXWIN1 is enabled, user need make sure every uplink channel has its own mapped RXWIN1 channel, or the modem may perform unexpected.

With this special RXWIN1 command, frequency shift between uplink and downlink becomes possible, then full-duplex is easy to achieve for the system if gateway supports.

a) Set RXWIN1

```
AT+RXWIN1=ch,freq  
eg: AT+RXWIN1=0,868.9
```


Set non zero **freq** to overwrite default RXWIN1 channel frequency.

Set zero **freq** to use default frequency

b) Query RXWIN1 channel

AT+RXWIN1=ch

eg: AT+RXWIN1=0,868100000

c) Check RXWIN1

AT+RXWIN1

+RXWIN1: 3; 0,868100000; 1,868300000; 2,868500000;

AT+RXWIN1 and its subcommands always returns the channels which are enabled currently. If customized downlink channel is zero, then default downlink channels will be used.

4.20 KEY

Change LoRaWAN related AES-128 KEY. If wrong key is used, your LoRaWAN modem will be rejected by LoRaWAN server. Contact server administrator to know what key should use. All KEYs are unreadable for security, the one who forgets his KEY need rewrite with a new key.

Format:

Change network session key (NWKSKEY)

AT+KEY=NWKSKEY, "16 bytes length key"

eg: AT+KEY=NWKSKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

eg: AT+KEY=NWKSKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: NWKSKEY 2B7E151628AED2A6ABF7158809CF4F3C

Change application session key (APPSKEY)

AT+KEY=APPSKEY, "16 bytes length key"

eg: AT+KEY=APPSKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

eg: AT+KEY=APPSKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: APPSKEY 2B7E151628AED2A6ABF7158809CF4F3C

Change application session key (APPKEY)

AT+KEY=APPKEY, "16 bytes length key"

eg: AT+KEY=APPKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

AT+KEY=APPKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: APPKEY 2B7E151628AED2A6ABF7158809CF4F3C

4.21 FDEFAULT

Reset LoRaWAN AT modem to factory default configuration.

Format:

AT+FDEFAULT
AT+FDEFAULT=Seeed

Return:

+FDEFAULT: OK

Item	Value
Mode	LoRaWAN ABP
Channel	3 default channels 868.1MHz 868.3MHz 868.5MHz
Datarate Range	DR0 : DR5
Unconfirmed Message Repetition	1
Confirmed Message Retry	3
Port	8
Datarate	DR0
ADR	ON
Power	14dBm
RXWIN2	869.525MHz, DR0
RXWIN1 Delay	1s
RXWIN2 Delay	2s
JOIN ACCEPT RXWIN1 Delay	5s
JOIN ACCEPT RXWIN2 Delay	6s
Listen Before Talk Threshold	-85dBm
EU868 Duty Cycle Limitation	OFF
LoRaWAN Public Network	ON
NwkSKey	2B7E151628AED2A6ABF7158809CF4F3C
AppSKey	2B7E151628AED2A6ABF7158809CF4F3C
AppKey	2B7E151628AED2A6ABF7158809CF4F3C
AppEui	8000000000000006
Uplink Counter	1
Downlink Counter	0
Multicast	OFF

Table 4-2 Factory default configuration

4.22 DFU

Use to enter DFU mode. If user need to enter DFU mode to update LoRaWAN modem firmware, then user should first send "AT+DFU=ON" command to enable firmware upgrade. Once DFU mode is on, user should repower LoRaWAN modem (unplug and plug back), after repowered LoRaWAN will enter DFU mode, user could use DfuSe tool to update the firmware. If user want to exit DFU mode without upgrade, user just need to repower again, LoRaWAN modem will exit DFU mode automatically.

For UART bootloader, "AT+DFU=ON" command will make device enter bootloader mode automatically.

For USB bootloader, after "AT+DFU=ON" command, user need restart device manually.

Format:

```
AT+DFU="New state"  
eg: AT+DFU=ON      // Enable DFU function  
eg: AT+DFU=OFF     // Disable DFU function  
AT+DFU=?           // Check if DFU is enabled configuration
```

Return:

```
+DFU: ON  
+DFU: OFF
```

Example:

```
+DFU: ON
```

Note: DFU mode is risky. Before updating, user must make sure the firmware is supplied by Seeed, a wrong firmware may brick LoRaWAN modem.

4.23 MODE

Use to select work mode. LWABP¹⁶, LWOTAA¹⁷, TEST are supported. LoRaWAN modem can only work with one mode at a time. By default, LWABP is enabled, all test commands are unavailable, LoRaWAN will return error(-12) if it receives test command in non-test mode.

"AT+MODE" command will reset LoRaWAN stack when first enter LWABP/LWOTAA mode and reset LoRa chip when first enter test mode.

LWABP/LWOTAA mode status is remembered by LoRaWAN modem, each time LoRaWAN modem starts, it will enter previous working mode before reset or repower.

Format:

```
AT+MODE="mode"  
eg: AT+MODE=TEST      // Enter TEST mode  
eg: AT+MODE=LWOTAA    // Enter LWOTAA mode  
eg: AT+MODE=LWABP     // Enter LWABP mode
```

Return

```
+MODE: LWABP          // Enter LWABP mode successfully  
+MODE: LWOTAA         // Enter LWOTAA mode successfully  
+MODE: TEST           // Enter TEST mode successfully
```

4.24 JOIN

When OTAA mode is enabled, JOIN command could use to join a known network.

Format:

```
AT+JOIN  
AT+JOIN=FORCE
```

¹⁶ LWABP is short for **LoRaWAN Activation By Personalization**. Check < LoRaWAN™ Specification > for details

¹⁷ LWOTAA is short for **LoRaWAN Over-The-Air-Activation**.

1. Join
 eg: AT+JOIN // Send JOIN request
2. Disconnect with current network, force send one JOIN request
 eg: AT+JOIN=FORCE
3. Returns
 - a) Join successfully
 +JOIN: Starting
 +JOIN: NORMAL
 +JOIN: NetID 000024 DevAddr 48:00:00:01
 +JOIN: Done
 - b) Join failed
 +JOIN: Join failed
 - c) Join process is ongoing
 +JOIN: LoRaWAN modem is busy

4.24.1 Specified Data Rate Join

Format:

AT+JOIN=DRx
AT+JOIN=FORCE

1. Join at DR0
 eg: AT+JOIN=DR5
2. Join at DR5
 eg: AT+JOIN=DR5

4.24.2 Auto Join

Since firmware v3.5.10 at modem provides a powerful auto join feature. It provides 3 most popular auto join strategy, AJMODE0, AJMODE1 and AJMODE2.

- AJMODE0: Fixed join period. And send JoinRequest at a random time of each period
- AJMODE1: Increasing join period from minimum to maximum at specified increasing sequence (MIN and MAX period are configured). Keep join period at the configured maximum period once join period becomes maximum. And send JoinRequest at a random time of each period.
- AJMODE2: Increasing join period from minimum to maximum at specified increasing sequence (MIN and MAX period are configured). Reset period to minimum period

1. Disable auto join. (By default auto join feature is disabled)
 AT+JOIN=0

In auto join mode host could still detect below format URC message to know device is connected

+JOIN: NetID 000024 DevAddr 48:00:00:01
+JOIN: Done

Note: AT+JOIN=DRx command can be not used with this data rate.

2. AJMODE0 specified command

Format:

Use fixed period to join (AJMODE0)

AT+JOIN=period // period: 0 - 172800s, 0 to disable auto join.

3. To configure AJMODE0, AJMODE1, AJMODE2

Format:

AT+JOIN=AUTO, min_period, max_period, steps

min_period: minimum join period configured, 0 - 172800s

max_period: maximum join period configured, 10 - 172800s

steps: how many steps it needs to increase from minimum to maximum period

Mode	min_period	max_period	steps
OFF	0	Any	Any
AJMODE0	None zero	0	Any
AJMODE1	None zero	None zero	0
AJMODE2	None zero	None zero	None zero

Rules:

- For AJMODE1 and AJMODE2, the increasing sequence used by AT Modem is $(N * (N + 1) / 2)$, Unit is min_period, which means the Nth period is $\text{min_period} * (N * (N + 1) / 2)$ s
- If calculated period is less than 10s, it is set to 10s
- If calculated period is greater than 172800s, it is set to 172800s
- If calculated period is greater than **max_period** it is set to **max_period**
- The period of which the number is equal to **steps** according to the auto join mode to either reset to minimum period or stays at maximum period.

4.25 BEACON

4.25.1 AT+BEACON

Set beacon and ping slot configuration

AT+BEACON=periodicity,[DRx],[psfreq],[DRx,bfreq] // Set beacon configuration

// periodicity: pingSlotPeriod factor (pingSlotPeriod = $2^{\text{periodicity}}$ seconds)

// DRx: Data rate

// psfreq: Ping slot frequency

// bfreq: Beacon frequency

// [: The field is omissible with all appended fields

Query beacon and ping slot configuration

AT+BEACON

+BEACON: periodicity,DRx,psfreq,DRx,bfreq

4.25.2 AT+BEACON=DMMUL

Dummy uplink control. Before switching to Class B mode, dummy uplink is supported by device to get configuration information. By default, dummy uplink is turned off.

AT+BEACON=DMMUL,num,period

num: 0 to disable, others to enable exact number of dummy uplinks, 0 ~ 255

period: uplink period, 5 ~ 17280s

AT+BEACON=DMMUL, 0, 15

4.25.3 AT+BEACON=INFO

Get beacon description information. Includes NetID, GatewayID, Gateway Coordinate

AT+BEACON=INFO

+BEACON: INFO, netid, gwid, longitude, latitude

netid: 3 bytes hex

gwid: 3 bytes hex

longitude: positive for east, negative for west. 123.124037 (East)

latitude: positive for north, negative for south. 89.002293 (North)

4.25.4 AT+BEACON=GWGPS

Get gateway GPS coordinate from last received beacon.


AT+BEACON=GWGPS

+BEACON: GWGPS, 123.124037, 89.002293

// 123.124037 Longitude (East)

// 89.002293 Latitude (North)

4.25.5 Switch to Class B mode



Command flow:

1. AT+CLASS=B
2. Wait +BEACON: LOCKED
3. Wait +BEACON: DONE
4. Device is now in Class B mode
5. When in Class B mode host should be responsible to monitor “+BEACON: LOST” event, when it occurs, which means device switch to Class A due to Beacon lost issue
6. If no beacon found during Class B switching process, “+BEACON: FAILED” is sent to host.
7. Current class mode is checkable through AT+CLASS command

Notification, will be triggered when the event occur.

```
+BEACON: LOCKED           // Beacon found and synced
+BEACON: FAILED           // Fail to switch to Class B
+BEACON: DONE             // Success to switch to Class B
+BEACON: LOST             // Beacon lost, switch back to Class A
```

4.25.5.1 ABP

Execute class switch AT command “AT+CLASS=B”, the modem will negotiate with server automatically.

```
AT+CLASS=B
```

When beacon is found, “+BEACON: LOCKED” message is notified.

```
+BEACON: LOCKED
```

When ping slot information is exchanged, “+BEACON: DONE” message is notified. At this time ping slots will be opened periodically

```
+BEACON: DONE
```

If there is not beacon is found in 128s, “+BEACON: FAILED” will be notified

If there is not beacon is found in 2 hour after beacon locked, “+BEACON: LOST” will be notified.

4.25.5.2 OTAA

Switch to OTAA mode.

```
AT+MODE=LWOTAA
```

Trigger AT+JOIN command to try to join the known LoRaWAN network.

```
AT+JOIN
```

Other information are the same as chapter 4.25.5.1 ABP.

4.26 CLASS

This command could enable LoRaWAN modem to work at different mode (Class A/B/C). LoRaWAN modem works at class A mode when power on, user need manually switch mode to class B/C as needed.

Format:

```
eg: AT+CLASS=A           // Enable Class A mode
eg: AT+CLASS=B           // Enable Class B mode
eg: AT+CLASS=C           // Enable Class C mode
```

Query class type:

```
AT+CLASS
+CLASS: A
+CLASS: C
+CLASS: B
+CLASS: B (Sx)           // Class B switching ongoing
```

4.26.1 Force Save Class Mode

By default, user need switch class mode every time again after module reset. If user need switch to one mode permanently, append "**SAVE**" parameter to original command to do it.

Format:

```
eg: AT+CLASS=A,SAVE // Enable Class A mode, permanently
eg: AT+CLASS=B,SAVE // Enable Class B mode, permanently
eg: AT+CLASS=C,SAVE // Enable Class C mode, permanently
```

4.26.2 Class C Downlink

Class C mode will reuse RXWIN2 configuration. Check with "AT+RXWIN2". If downlink is received, below message could be returned to host.

```
+MSG: FPENDING
+MSG: Link 20, 1
+MSG: ACK Received
+MSG: MULTICAST
+MSG: PORT: 8; RX: "12345678"
+MSG: RXWIN0, RSSI -106, SNR 4
+MSG: Done
```

4.26.3 Class B Downlink

Check with "AT+BEACON" current beacon and ping slot configuration. If downlink is received, below message could be returned to host. RXWIN3 stands for ping slot received packet.

```
+MSG: FPENDING
+MSG: Link 20, 1
+MSG: ACK Received
+MSG: MULTICAST
+MSG: PORT: 8; RX: "12345678"
+MSG: RXWIN3, RSSI -106, SNR 4
+MSG: Done
```

4.26.4 Class B Status

```
+CLASS: B (S0) // (Status 0, Beacon timing request)
+CLASS: B (S1) // (Status 1, Beacon searching)
+CLASS: B (S2) // (Status 2, Ping slot information request)
+CLASS: B (S3) // (Status 3, Failed)
+CLASS: B (S4) // (Status 4, Not synced)
+CLASS: B (S5) // (Status 5, Network not joined)
+CLASS: B (S6) // (Status 6, LoRaWAN is busy)
+CLASS: B (S7) // (Status 7, Send dummy uplink)
+CLASS: B // (Class B mode enabled)
```

4.27 DELAY

RX window delay configuration command. Supports configure RECEIVE_DELAY1, RECEIVE_DELAY2, JOIN_ACCEPT_DELAY1, JOIN_ACCEPT_DELAY2.

Command	Item	Comments
AT+DELAY=RX1, ms	RECEIVE_DELAY1	RX window 1 delay time
AT+DELAY=RX2, ms	RECEIVE_DELAY2	RX window 1 delay time
AT+DELAY=JRX1, ms	JOIN_ACCEPT_DELAY1	Join accept RX window 1 delay time
AT+DELAY=JRX2, ms	JOIN_ACCEPT_DELAY2	Join accept RX window 2 delay time

Table 4-3 LoRaWAN Delay Items

Format:

```
// Query delay settings
AT+DELAY
AT+DELAY?
AT+DELAY=?

// Set delay
AT+DELAY=RX1, 1000 // Unit: ms
AT+DELAY=RX2, 2000
AT+DELAY=JRX1, 5000
AT+DELAY=JRX2, 6000
```

Return:

```
+DELAY RX1, 1000
+DELAY RX2, 2000
+DELAY JRX1, 5000
+DELAY JRX2, 6000
```

4.28 LW

LW commands is a collection of several LoRaWAN control commands. Include CDR, ULDL, DC, NET, MC, THLD. BAT, TPS, SCR, JDC, LEN.

4.28.1 CDR

CDR command could be used to get current TX/RX available data rate range.

Format:

```
AT+LW=CDR, [ UL_DR_MIN, UL_DR_MAX, DL_DR_MIN, DL_DR_MAX ]
```

1. Check current datarate limitation

```
AT+LW=CDR
+LW: CDR, TXDR(0,7), RXDR(0,7) //EU868
+LW: CDR, TXDR(0,4), RXDR(8,13) //AU920
```

4.28.2 ULDL

Set and read uplink and downlink counter.

Format:

```
AT+LW=ULDL, UL_COUNTER, DL_COUNTER
```

1. Read counter

```
AT+LW=ULDL
+LW: ULDL 1, 0
```

2. Set counter

```
AT+LW=ULDL, 5, 10
```

+LW: ULDL 5, 10

4.28.3 DC

EU868 Duty Cycle limitation and LoRaWAN Transmit Duty Cycle control interface. This option is mandatory to be set to on, when using in Europe to follow ETSI regulation. And this command could also be used to set a specify value for **MaxDCycle**, valid range 0 ~ 15. And the transmit aggregated duty cycle is allowed by:

$$AggregatedDutyCycle = \frac{1}{2^{MaxDCycle}}$$

A value of 0 corresponds to “no duty cycle limitation” except the one set by the regional regulation.

MaxDCycle	$2^{MaxDCycle}$	Aggregated Duty Cycle
0	1	100.000%
1	2	50.000%
2	4	25.000%
3	8	12.500%
4	16	6.250%
5	32	3.125%
6	64	1.563%
7	128	0.781%
8	256	0.391%
9	512	0.195%
10	1024	0.098%
11	2048	0.049%
12	4096	0.024%
13	8192	0.012%
14	16384	0.006%
15	32768	0.003%

Table 4-4 Duty Cycle Control

Format:

AT+LW=DC, "ON/OFF"
AT+LW=DC, MaxDCycle

Return format:

+LW=DC, "ON/OFF", MaxDCycle

1. Check DC option

AT+LW=DC

+LW: DC, ON, 0 // EU868 Duty Cycle ON, MaxDCycle is 0

2. Set EU868 ETSI Duty Cycle on

AT+LW=DC, ON

+LW: DC, ON, 0 //

3. Set EU868 ETSI Duty Cycle off

AT+LW=DC, OFF

+LW: DC, OFF

4. Set LoRaWAN MaxDCycle

AT+LW=DC

+LW: DC, ON, 0 // EU868 Duty Cycle ON, MaxDCycle is 0

+LW: DC, OFF, 1 // EU868 Duty Cycle OFF or not in EU868 mode, MaxDCycle is 0

4.28.4 NET

This command is used to choose public LoRaWAN network or private network. Set ON to choose public network, set OFF to choose private network.

Format:

AT+LW=NET, "ON/OFF"

1. Check network type

AT+LW=NET

+LW: NET, ON

2. Set public network on

AT+LW=NET, ON

+LW: NET, ON

3. Set public network off

AT+LW=NET, OFF

+LW: NET, OFF

4.28.5 MC

MC command could enable an extra broadcast address for LoRaWAN modem. This command is useful when using Class B or C mode, to control a group of devices which has the same multi cast address at the same time to use a broadcast downlink command.

Format:

AT+LW=MC,["ON/OFF"],["DEVADDR"],["NWKSKEY"],["APPSKEY"],["COUNTER"]

1. Check multi cast status

AT+LW=MC

+LW: MC, OFF, 00cf3e72, 0

2. Set MC parameters

AT+LW=MC,ON,"11223344","2B7E151628AED2A6ABF7158809CF4F3C","2B7E151628AED2A6ABF7158809CF4F3C",0

+LW: MC, ON, 11223344, 0

Default MC_NWKSKEY and MC_APPKEY both are **2B7E151628AED2A6ABF7158809CF4F3C**.

4.28.6 THLD

Listen before talk threshold control, available value -1 ~ -140 (dBm).

Format:

AT+LW=THLD, thresh_hold

1. Check current threshold level

AT+LW=THLD

+LW: THLD, -90

2. Set new threshold

AT+LW=THLD, -85

+LW: THLD, -85

4.28.7 BAT

Set DevStatusReq/DevStatusAns battery level value. Available value 0 ~ 255

1. Check current threshold level

AT+LW=BAT

+LW: BAT, 255

- Set new threshold

AT+LW=BAT, 100

+LW: BAT, 100

4.28.8 TPS

TPS command can be used to set default TX parameter. **UplinkDwellTime** and **DownlinkDwellTime** option is just for AS923. **MaxEIRP** is for all bands.

Format:

AT+LW=TPS

AT+LW=TPS, UplinkDwellTime, DownlinkDwellTime, MaxEIRP

UplinkDwellTime: ON/OFF

DownlinkDwellTime: ON/OFF

MaxEIRP: 0~15

Return:

+LW: TPS, UplinkDwellTime, DownlinkDwellTime, MaxEIRP

Example:

AT+LW=TPS, ON, ON, 7

+LW: TPS, ON, ON, 7

4.28.9 SCR

SCR (Sequence counter Checking Relaxed) command could be used to disable strict downlink frame counter checking. Which is useful for some application, especially in the case which server can't reset downlink counter automatically.

Format:

AT+LW=SCR

AT+LW=SCR, ON

AT+LW=SCR, OFF

Return

+LW: SCR, OFF

+LW: SCR, ON

NOTE: If SCR is enabled, there may be security issue, if some recorder downlink and replay back to your device. Be careful to use this command.

NOTE: If SCR is enabled by default since firmware v2.1.16, disable it if you need more security.

4.28.10 JDC

JDC command could be used to disable the JoinRequest duty cycle limitation.

Format:

AT+LW=JDC

AT+LW=JDC, OFF

AT+LW=JDC, ON

Return:

+LW: JDC, ON

+LW: JDC, OFF

4.28.11 CT

CT command can be used to enable or disable strict lorawan compliance test mode. When disabled AT modem will optimize several lorawan features to make it more usable for application. By default It is disabled.

Format:

AT+LW=CT
AT+LW=CT, ON
AT+LW=CT, OFF

Return:

+LW: CT, ON
+LW: CT, OFF

Index	Description
1	Downlink ACK of Confirmed uplink is no need to check, any valid downlink will terminate the confirmed downlink transaction.
2	When under ADR off mode, LinkAdrReq Datarate and TxPower configuration will be ignored and keep settings unchanged. And will reply always ACK
3	CN470/US915/AU915 band supports to use DIChannelReq command to configure downlink channel frequency
4	EU868 band is available to configure out of range channels to make customized band plans
5	

4.28.12 LEN

LEN command can be used to get maximum payload length which is supported to send according to current data rate.

Format:

AT+LW=LEN

Return:

+LW: LEN, 50

*Note: If "AT+LW=LEN" returns 0 length. User must send a dummy **AT+MSG** command to flush the internal MAC command buffer. And continue to send more data.*

4.28.13 VER

Note: don't change unless you know what you are doing.

Switch LoRaWAN protocol version.

Format:

AT+LW=VER, Vxx

Version	Description
V10	See V102
V101	See V102
V102	Legacy LoRaWAN 102, Class B beacon is in UTC epoch format, beacon timing will be influenced by leap second, class B of V102 is deprecated. Protocol: LoRaWAN102-20161012_1398_1.pdf

	Regional Parameter: LoRaWANRegionalParametersv1.0.2_final_1944_1.pdf
V102B	Default setting. LoRaWAN alliance recommended Class B protocol. Protocol: LoRaWAN1.0.2_classB_draft4-clean.pdf Regional Parameter: LoRaWANRegionalParametersv1.0.2_final_1944_1.pdf
V103	Latest LoRaWAN alliance v1.0.x protocol. Protocol: lorawan1.0.3_final.pdf Regional Parameter: LoRaWAN Regional Parameters v1.0.3 revA.pdf
V102ALPHA	The only difference between V102ALPHA and V102B is V102B use DeviceTimeReq to sync time with NS, but V102ALPHA use BeaconTimingReq. Protocol: LoRaWAN102-20161012_1398_1.pdf + LoRaWAN1.1_draft_30.pdf (Class B Section) Regional Parameter: LoRaWANRegionalParametersv1.0.2_final_1944_1.pdf
V11	Not supported yet Protocol: LoRaWAN-v1.1.pdf(October 11, 2017) Regional Parameter: LoRaWAN-Regional-Parameters-v1.1rA.PDF(October 11, 2017)

Example:

AT+LW=VER,V102B
+LW: VER, V102B

4.28.14 DTR

Buffer DeviceTimeReq MAC command for AT modem, the MAC command will be sent in next LoRaWAN transaction controlled by command **MSG/CMSG/MSGHEX/CMSGHEX**

Format:

AT+LW=DTR

It is recommended to use MSGHEX and CMSGHEX to carry this command if there is no application payload to send.

4.28.15 LCR

Buffer LinkCheckReq MAC command for AT modem, the MAC command will be sent in next LoRaWAN transaction controlled by command **MSG/CMSG/MSGHEX/CMSGHEX**

Format:

AT+LW=LCR

It is recommended to use MSGHEX or CMSGHEX to carry this command if there is no application payload to send.

4.28.16 LDRO

This command could be used to configure Low Data Rate Optimize option. Which supports 3 status, AUTO, ON and OFF. Default mode is AUTO. (Note: this conjuration is not memorable, it is set to AUTO mode when power on or reset)

Format:

AT+LW=LDRO
AT+LW=LDRO,AUTO
AT+LW=LDRO,ON
AT+LW=LDRO,OFF

Example:

AT+LW=LDRO
+LW: LDRO, AUTO

AUTO mode: (LoRaWAN configuration)

Data Rate	Low Data Rate Optimize
SF11/BW125	ON
SF12/BW125	ON
SF12/BW250	ON
Others	OFF

Use in LoRaWAN mode:

1. Run **AT+LW=LDRO** command
2. It will effect in next transaction (Class A uplink and RX windows, or Class B beacon and ping windows)

Use in TEST mode:

1. Run **AT+LW=LDRO** command
2. Run "**AT+LW=RFCFG,freq,sf**" command to effect it.

Example:

1. **AT+MODE=TEST**
2. **AT+LW=LDRO,ON**
3. **AT+TEST=RFCFG,freq,sf,bw,....**
4. **AT+TEST=TXLRPKT** to send packet or **AT+TEST=RXLRPKT** to receive

Note: If LDRO option is not matched between TX and RX, then on receiver side it probably can't receive packet or receive damaged packet

4.28.17 DCMRX

DCMRX could be used to disable Confirmed Message RX window to speed up uplink period for Gateway or Server test purpose

Format:

AT+LW=DCMRX
AT+LW=DCMRX,ON
AT+LW=DCMRX,OFF

Example:

AT+LW=DCMRX
+LW: DCMRX, ON

4.28.18 DUMRX

DUMRX could be used to disable Unconfirmed Message RX window to speed up uplink period for through output uplinks to server in short time to optimize application power consumption and efficiency.

Format:

AT+LW=DUMRX
AT+LW=DUMRX,ON
AT+LW=DUMRX,OFF

Example:

AT+LW=DUMRX

+LW: DUMRX, ON

4.28.19 AFPACK

AFPACK could be enabled to make the AT modem Auto ACK FPending bit to ease the end-device design. When enabled device will wait to timeout if FPending bit is set

Format:

```
AT+LW=AFPACK
AT+LW=AFPACK,0           // disable AFPACK function
AT+LW=AFPACK,1~172800   // enable AFPACK, and set timeout to N seconds
```

Example:

```
AT+LW=AFPACK
+LW: AFPACK, 0~172800
```

4.28.20 CHRFB

CHRB can be set to enable or disable channel configuration roll back features. Channel roll back feature in standard LoRaWAN protocol could complex the server and end-device design and could lead to channel configuration non-synced issue. It is recommended to set CHRB OFF to disable channel roll back feature (Default setting).

Format:

```
AT+LW=CHRB
AT+LW=CHRB,OFF           // disable channel roll back feature
AT+LW=CHRB,ON           // enable channel roll back feature
```

Example:

```
AT+LW=CHRB
+LW: CHRB, OFF
```

4.29 WDT

WDT command can be used to turn on/off internal watchdog. The watchdog is on by default, this will enhance the module stability, especially under the condition of severe electromagnetic environment. After WDT is turned on, the sleep current will be increased by around 0.7uA.

Format:

```
AT+WDT
AT+WDT=ON
AT+WDT=OFF
```

Return:

```
+WDT: ON
+WDT: OFF
```

4.30 LOWPOWER

Sleep command could be used to make modem enter sleep mode with ultra-low power consumption, check device datasheet to know detailed parameters. After device enters in sleep mode, host device could send any character to wakeup it, after this host should wait at least 5ms to send next commands, so that modem could get ready. A C code example is attached to show how to handle LOWPOWER mode.

During the LOWPOWER mode, level of UART RX pin must keep unchanged, any signal on UART RX pin will make modem exit LOWPOWER mode. When LOWPOWER mode is triggered, there are extra

30ms before modem really enter sleep mode, host device should use this time to de-initial its UART if it is needed.

It also supplies feature to set a lowpower alarm from 100ms to 129600000ms (36hrs).

Format:

```

eg: AT+LOWPOWER                // Sleep until woke up by UART TX
eg: AT+LOWPOWER=1000           // Sleep 1000ms until timeout
eg: AT+LOWPOWER=AUTOON         // Enter extremely low power mode
eg: AT+LOWPOWER=AUTOOFF18     // Exit extremely low power mode
                                // Query symbol is not available
  
```

Return

```

+LOWPOWER: SLEEP                // Enter SLEEP mode successfully
+LOWPOWER: WAKEUP              // Modem is woke up.
  
```

Example:

```

AT+LOWPOWER=1000
+LOWPOWER: WAKEUP
  
```

Note: Extra 0x55 will be sent to host mcu to perform a wakeup signal for it, LoRaWAN AT Modem will wait for 15ms before sending "+LOWPOWER: WAKEUP" frame , host MCU could use this 15ms to initialize then to receive the WAKEUP frame.

C example:

```

printf("AT+LOWPOWER\r\n");// Set low-power mode
// ...
// HOST do other operation.
// ...
printf("A");                // Send any character to wake-up the modem
DelayMs(5);                 // Wait modem ready
printf("AT+ID\r\n");// New operation
  
```

4.30.1 Low Power Auto Mode

AT+LOWPOWER=AUTOON command could be used to enable extremely low power mode. In this mode modem will enter deep sleep mode when it is idle. The idle status means no ongoing receiving commands, no ongoing LoRaWAN service needed. If this mode is enabled, when sending commands to modem, at least four 0xFFs need to be added to the start of each AT command. At the same time, each return message is also added with four 0xFFs. The host mcu parser should be able to handle these wakeup characters.

Example to send AT+ID command with low power auto mode

0xFF	0xFF	0xFF	0xFF	'A'	'T'	'+'	'I'	'D'	'\r'	'\n'
------	------	------	------	-----	-----	-----	-----	-----	------	------

Use AT+LOWPOWER=AUTOOFF command to turn off low power auto mode, four 0xFFs are also needed to add to the start of the command.

FF	FF	FF	FF	A	T	+	L	O	W	P	O	W	E	R	=	A	U	T	O	O	F	F	\r	\n
FF	FF	FF	FF	61	74	2B	6C	6F	77	70	6F	77	65	72	3D	61	75	74	6F	6F	66	66	0D	0A

¹⁸ It is better to use AT+LOWPOWER=AUTOOFF always with heading 0xFFs

Below hex string equals to the table above, send it to modem in hex format could also disable the low power auto on feature.

```
FFFFFFFF61742B6C6F77706F7765723D6175746F6F666660D0A
```

C example:

```
uint8_t buf[256];
printf("AT+LOWPOWER=AUTOON\r\n");// Set low-power auto on mode
// ...
// HOST do other operation.
// ...
buf[0] = 0xFF;
buf[1] = 0xFF;
buf[2] = 0xFF;
buf[3] = 0xFF;
//DelayMs(5); // If user use higher baud rate than 9600, uncomment this line
sprintf(buf+4, "AT+MSG=\"%string\"\r\n");
uart_putbuf(buf, strlen(buf)+4); // Send command to LoRaWAN modem
```

4.31 VDD

Get supply voltage, return value in unit 0.01V. Format:

```
AT+VDD
AT+VDD?
AT+VDD=?
```

Example:

```
AT+VDD
+VDD: 3.30V
```

4.32 TEMP

Get temperature, return value in unit °C. Format:

```
AT+TEMP
AT+TEMP?
AT+TEMP=?
```

Example:

```
AT+TEMP
+TEMP: 20.5
```

Note: Temperature command returns temperature sensed by on chip sensor which gives precision about +/-5°C in worst case, this feature provides a cheap temperature measurement solution for low precision application

4.33 RTC

Get real time from LoRaWAN modem. When modem is powered on, it always starts from 2000-01-01 00:00:00, user could set new time to modem to sync to the real time.

1. Check current time

```
AT+RTC
+RTC: 2000-01-01 01:00:28 // this means the modem has kept running for 1 hour
```

2. Set new time to "2016-06-14 18:16:11", this format is very critical, must keep the same format as "yyyy-MM-dd HH:mm:ss", year must starts with 20xx.
AT+RTC="2016-06-14 18:16:11"
+RTC: 2016-06-14 18:16:11
3. Get time zone
AT+RTC=ZONE
+RTC: ZONE, +00:00
4. Set time zone
AT+RTC=ZONE, "+08:00"
+RTC: ZONE, +00:00
5. Get verbose RTC time
AT+RTC=FULL
+RTC: YY-MM-DD hh:mm:ss UTCshh:mm, epoch, age
UTCshh:mm: s -> -/+, hh -> hour, mm -> minute
epoch: GPS epoch (if LoRaWAN V102 is enabled it is in UTC epoch¹⁹)
age: device start up age in second (AT+RESET / POWER ON / WDT Reset clears age to 0)
6. Check Leap seconds setting
AT+RTC=LEAPSEC
+RTC: LEAPSEC, 37
7. Set new leap seconds
AT+RTC=LEAPSEC,37
+RTC: LEAPSEC, 37
8. Get UTC time in ms
AT+RTC=UTCMS
+RTC: 2016-06-14 18:16:11.576

4.33.1 Time Synchronization

When modem is powered on, it always starts from 2000-01-01 00:00:00, there are 3 ways for user to sync real time:

- user could set new time to modem to sync to the real time.
- Use AT+LW=DTR command trigger DeviceTimeReq to sync time manually
 - LoRaWAN V102B or higher protocol
- In class B mode, time will be synchronized with beacon automatically

4.33.2 Leap second

Check <http://www.ietf.org/timezones/data/leap-seconds.list> to know the leap second list. As of this document (year 2017), there has been 37 leap seconds ever. The firmware has preset this value to calculate the UTC time. In the future, more leap seconds will occur, at that time user should update the leap second to real one so that AT+RTC command returns right time.

4.33.3 Time Zone

AT+RTC=ZONE command can be used to set time zone. Default set to UTC+00:00.

¹⁹ UTC epoch is already deprecated by LoRa Alliance due to the leap second issue, however AT modem keeps this mode for users whose LoRaWAN server still doesn't support GPS epoch

4.34 EEPROM

LoRaWAN Modem supports maximum 256 bytes to save user data. Format:

```
AT+EEPROM=ADDR
AT+EEPROM=ADDR,VAL
```

Return:

```
+EEPROM: ADDR, VAL
```

Both ADDR and VAL are in hex format. Valid range is 0x00 ~ 0xFF. Example:

```
AT+EEPROM=00, AB
+EEPROM: 00, AB
```

4.35 UART

4.35.1 TIMEOUT

LoRaWAN AT modem supports UART receive timeout feature, AT parser inside the modem start counts from first "AT" character is received, when counter overflows, a "Input timeout" event will be triggered. One message like below will be showed. Maximum timeout value is 300ms.

```
+INFO: Input timeout
```

```
AT+UART=TIMEOUT, 0      // Disable timeout feature
AT+UART=TIMEOUT, 1000   // Set timeout 1s feature
AT+UART=TIMEOUT         // Get timeout value
```

4.35.2 BR

BR command could be used to set new baud rate. Available baud rate are 9600 14400 19200 38400 57600 76800 115200 and 230400. New baud rate will be validated after reset or repower.

Format:

```
AT+UART=BR
AT+UART=BR, br
```

Return:

```
+UART=BR, br
```

4.36 TEST

TEST command is not like other command, it is a serious command, includes several sub-commands, refer to table below. With test mode, user could do RF performance test quickly without any knowledge of LoRa chip. Commands which are related to RF configuration is disabled in test mode.

Sub-Command	Comment
STOP	Set LoRaWAN Modem to TEST stop mode
TXCW	Transmit continuous wave
TXCLORA	Transmit continuous LoRa signal
RFCFG	Set RF configuration in TEST mode
RXLRPKT	Continuous receive pure LoRa packet, print once there is new packet received
TXLRPKT	Send one HEX format packet out
TXLRSTR	Send one string format packet
RSSI	Get RSSI value of specified channel
LWDL	Send LoRaWAN downlink packet, useful tool to test CLASS C device

Table 4-5 TEST mode sub-command list

4.36.1 Help Information

STOP -- AT+TEST=STOP

HELP -- AT+TSET=HELP

TXCW -- AT+TEST=TXCW

TXCLORA -- AT+TEST=TXCLORA

RFCFG -- AT+TEST=RFCFG,[F],[SF],[BW],[TXPR],[RXPR],[POW],[CRC],[IQ],[NET]

RXLRPKT -- AT+TEST=RXLRPKT

TXLRPKT -- AT+TEST=TXLRPKT,"HEX"

TXLRSTR -- AT+TEST=TXLRSTR,"TEXT"

RSSI -- AT+TEST=RSSI,F,[CNT]

LWDL -- AT+TEST=LWDL,TYPE,DevAddr,"HEX",[FCNT],[FPORT],[FCTRL]

"["] means the parameter is omissible together with parameters behind it

4.36.2 Enter TEST mode

Before use any TEST command, LoRaWAN should work in test mode, or error code -12 will be reported.

Command:

AT+MODE=TEST

Return:

+MODE: TEST // LoRaWAN modem enter TEST mode successfully

4.36.3 Query RF configuration

First thing after enter TEST mode should be check RF configuration.

Command:

AT+TEST=? // Query test mode and RF configuration

Return Error:

+TEST: ERROR(-12)

When come with ERROR(-12), user could try "AT+MODE=?" to check if LoRaWAN modem is in TEST mode, if not user should enter test mode first.

Return STOP:

+TEST: STOP
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, NET:ON

Return TXLRPKT:

+TEST: TXLRPKT
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, NET:ON

Return RXLRPKT:

+TEST: RXLRPKT
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, NET:ON

Return TXCW:

+TEST: TXCW
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, NET:ON

4.36.4 Set RF Configuration

RFCFG supports set frequency, SF, band width, TX preamble, RX preamble and TX power settings. TX and RX shares all configuration except "preamble length", user could choose different preamble length. For LoRa communication, it is strongly recommended to set RX preamble length longer than TX's. Bandwidth only supports 125KHz / 250KHz / 500KHz.

Depend on Semtech SX1276 (PA_BOOST/RFO) and design solution of Seeed module, MAX output power of different band LoRaWAN modem could be different. Check below table about the details.

Device	Bootloader	Interface	LF Band ²⁰	HF Band ²¹
LoRa-E5	UART	UART	22dBm	22dBm

Table 4-6 MAX output power of HF and LF band

Format:

"["] means the parameter is omissible together with parameters after it

AT+TEST=RFCFG,[FREQUENCY],[SF],[BANDWIDTH],[TX PR],[RX PR],[TX POWER],[CRC],[IQ],[NET]

eg: AT+TEST=RFCFG,866,SF12,125,12,15,14,ON,OFF,OFF

FREQUENCY: 866MHz
SpreadFactor: SF12
BandWidth: 125KHz
TX Preamble: 12
RX Preamble: 15
Power: 14dBm

²⁰ LF Band: Frequency is less than 525MHz

²¹ HF Band: Frequency is larger than 525MHz

CRC: ON
Inverted IQ: OFF
Public LoRaWAN: OFF

Return:

+TEST: RFCFG F:868100000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, PNET:ON

4.36.5 TX LoRa Packet

After enter test mode, user could send LoRa packet through "AT+TEST=TXLRPKT" sub-command. The command format is like below:

AT+TEST=TXLRPKT, "HEX STRING"

Command sequence to send LoRa packet:

```
// Set test mode
AT+MODE=TEST
// Query test mode, check RF configuration
AT+TEST=?
// Set RF Configuration
AT+TEST=RFCFG,[FREQUENCY],[SF],[BANDWIDTH],[TXPR],[RXPR],[POW],[CRC],[IQ],[NET]
// Send HEX format packet
AT+TEST=TXLRPKT, "HEX String"
eg:AT+TEST=TXLRPKT, "00 AA 11 BB 22 CC"
// Send TEXT format packet
AT+TEST=TXLRSTR, "TEXT"
eg:AT+TEST=TXLRSTR, "LoRaWAN Modem"
```

Return:

```
+TEST: TXLRPKT "404EA99000800A00089F6E770959"
+TEST: TXLRSTR "LoRaWAN Modem"
+TEST: TX DONE
```

4.36.6 RX LoRa Packet

After enter test mode, user could enter LoRa packet continuous RX mode through RXLRPKT sub-command. Like below:

AT+TEST=RXLRPKT

Command sequence to receive LoRa packet:

```
// Set test mode
AT+MODE=TEST
// Query test mode, check RF configuration
AT+TEST=?
// Set RF Configuration
AT+TEST=RFCFG,[FREQUENCY],[SF],[BANDWIDTH], [TXPR],[RXPR],[POW],[CRC],[IQ],[NET]
// Enter RX continuous mode
AT+TEST=RXLRPKT
```

Return:

```
+TEST: LEN:250, RSSI:-106, SNR:10
```

+TEST: RX 404EA99000800A00089F6E770959

4.36.7 TX Continuous Wave

Before enable TXCW function, right frequency and TX power should be set. Format:

AT+TEST=TXCW

Return:

+TEST: TXCW

4.36.8 TX Continuous LoRa

Before enable TXCLORA function, right frequency and TX power should be set. Format:

AT+TEST= TXCLORA

Return:

+TEST: TXCLORA

4.36.9 RSSI

Read RSSI from a specified channel. Format:

AT+TEST = RSSI, frequency(MHz), [times]

Return:

+TEST: RSSI, average, maximum, minimum

4.36.10 LWDL

LWDL command is designed to test LoRaWAN modem CLASS C function. Use this command, user can easily send data to a working LoRaWAN Class C device.

AT+TEST = LWDL, TYPE, "DevAddr", "HEX STRING", [FCNT], [FPORT], [FCTRL]

FCNT: HEX

FPORT: Decimal

FCTRL: HEX

Return:

AT+TEST=LWDL,MSG,"009291ad", "14 54 54 88 08 93 122 35", 1, 5, 00

+TEST: LWDL "A0AD91920000010005134D37EA53E3023A9F0125D234"

+TEST: LWDL TX DONE

Note: Must use AT+TEST=RFCFG command to set CRC OFF, IQ ON, NET ON before sending LoRaWAN downlink.

4.36.1 Beacon Sniffer

AT+TEST=BEACON command can be used to set AT modem into beacon sniffer mode, which could be useful for server and gateway designer to debug beacon timing.

Format:

AT+TEST=BEACON

+TEST: BEACON

When beacon is received one beacon message is returned to host controller.

+TEST: BEACON, ms, payload, rssi, snr, ticks, vdd, temp

ms: beacon received time in ms

payload: hex string

rssi: unit dBm

*snr: unit dB
ticks: unit 8192Hz
vdd: unit 0.01V
temp: unit 0.01°C*

Before use Beacon, user also need use AT+TEST=RFCFG command to set CRC OFF, IQ OFF, NET ON, and use AT+DR=band to select correct band, use AT+LW=VER command to select correct LoRaWAN protocol.

Command flow to sniff EU868 beacon:

```
AT+DR=EU868  
AT+LW=VER,102B  
AT+MODE=TEST  
AT+TEST=RFCFG, 869.525, SF9, 125, 8, 8, 20, OFF, OFF, ON  
AT+TEST=BEACON
```

```
+TEST: BEACON, 232509, 0000804D67475A28000000000000000000, -66, 5, 1905042, 320, 2197  
+TEST: BEACON, 232509, 0000804D67475A28000000000000000000, -66, 5, 1905042, 320, 2197  
+TEST: BEACON, 360509, 0000004E674732AC000000000000000000000, -66, 5, 2953807, 319, 2187  
+TEST: BEACON, 488510, 0000804E67470A7100000000000000000000, -66, 5, 4002572, 319, 2223  
+TEST: BEACON, 616511, 0000004F6747029B00000000000000000000, -66, 4, 5051336, 319, 2223  
+TEST: BEACON, 744512, 0000804F67473A4600000000000000000000, -66, 5, 6100101, 319, 2205
```

Note: For beacon frequency hopping band like US915/CN470/AU915, BEACON sniffer mode can only sniff a single selected channel.

4.37 LOG

LOG command is for user debugging purpose, after log is enabled, AT modem will returns extra log message to host controller, check these log could help user locate issue quickly when it happens. Log is turned by default.

Format:

```
AT+LOG=level // DEBUG/INFO/WARN/ERROR/FATAL/PANIC/QUIET
```

Enable log:

```
AT+LOG=DEBUG
```

Disable log:

```
AT+LOG=QUIET
```

Note: if log is enabled it will takes extra energy, for low power application it is recommended to turn off log.

Revision

V1.0 2020-07-20 First release