

### Introduction

The 32F723EDISCOVERY Discovery kit is a complete demonstration and development platform for the STMicroelectronics ARM® Cortex®-M7 core-based STM32F723IEK6 microcontroller. It features the following interfaces: three I<sup>2</sup>Cs, five SPIs with three multiplexed simplex I<sup>2</sup>S, 2xSDMMC, FMC, Quad-SPI. It also features four USARTs and four UARTs peripherals, one CAN bus, three 12-bit ADCs, two 12-bit DACs, two SAIs, internal 256 Kbytes of SRAM, 512 Kbytes of Flash memory, one USB OTG HS internal PHY, USB OTG FS and SWD debugging support. This 32F723EDISCOVERY Discovery kit offers everything required for users to get started quickly and develop applications easily.

The full range of hardware features on the board helps users to evaluate almost all peripherals (USB OTG HS and FS, USART, SAI Audio DAC stereo with audio jack input and output, ST-MEMS digital microphones, external PSRAM, Quad-SPI Flash memory, LCD with capacitive multi-touch panel and others) and develop applications. Arduino™ Uno V3, PMOD and STMod+ connectors allow easy connection of extension shields or daughterboards for specific applications.

The integrated ST-LINK/V2-1 provides an embedded in-circuit debugger and programmer for the STM32.

The 32F723EDISCOVERY Discovery kit comes with comprehensive free software libraries and examples available with the STM32Cube package.

Figure 1. 32F723EDISCOVERY (top view)





Figure 2. 32F723EDISCOVERY (bottom view)



1. Pictures are not contractual.

# Contents

- 1      Features ..... 7**
- 2      Product marking ..... 8**
- 3      System requirements ..... 8**
- 4      Development toolchains ..... 8**
- 5      Demonstration software ..... 9**
- 6      Ordering information ..... 9**
- 7      Hardware layout and configuration ..... 10**
  - 7.1    The 32F723EDISCOVERY Discovery kit layout ..... 11
  - 7.2    The 32F723EDISCOVERY Discovery kit mechanical drawing ..... 13
  - 7.3    Embedded ST-LINK/V2-1 ..... 14
    - 7.3.1    Drivers ..... 14
    - 7.3.2    ST-LINK/V2-1 firmware upgrade ..... 15
  - 7.4    Power supply ..... 15
    - 7.4.1    Supplying the board through the ST-LINK USB port (default setting) .. 15
    - 7.4.2    Supplying the board through a charger connected to ST-LINK ..... 16
    - 7.4.3    Supplying the board from E5V (CN3 or CN12) ..... 17
    - 7.4.4    Supplying the board from an external power supply through USB HS . 18
    - 7.4.5    Supplying the board from an external power supply through USB FS . 18
  - 7.5    Programming/debugging when the power supply is not from ST-LINK ..... 18
  - 7.6    Clock sources ..... 19
  - 7.7    Reset sources ..... 19
  - 7.8    Audio ..... 19
  - 7.9    USB OTG HS ..... 20
  - 7.10    USB OTG FS ..... 20
  - 7.11    PSRAM memory ..... 21
  - 7.12    Quad-SPI NOR Flash memory ..... 21
  - 7.13    Virtual COM port ..... 21

7.14	TFT LCD 240x240 pixels	21
7.15	Capacitive Control Touch panel	21
7.16	Buttons and LEDs	21
<b>8</b>	<b>Connectors</b>	<b>23</b>
8.1	Wi-Fi ESP-01 compatible connector	23
8.2	Arduino Uno V3 compatible connectors	23
8.3	PMOD and STMod+ connectors P2 and P1	24
8.3.1	PMOD connector P2	25
8.3.2	STMod+ connector P1	26
8.4	TAG connector CN9	27
8.5	USB OTG HS Micro-AB connector	28
8.6	USB OTG FS Micro-AB connector	28
8.7	LCD Frida connector	29
8.8	Control Touch Panel (CTP) Frida connector	30
8.9	ST-LINK/V2-1 USB Micro-B connector CN1	31
8.10	Audio stereo speakers	31
8.11	Audio line connectors	31
8.11.1	Audio line output (green jack) connector	32
8.11.2	Audio line input (blue jack) connector	32
<b>Appendix A</b>	<b>32F723EDISCOVERY Discovery board I/O assignment</b>	<b>33</b>
<b>Appendix B</b>	<b>Electrical schematics</b>	<b>38</b>
<b>Appendix C</b>	<b>PMOD and STMod+ schematic table</b>	<b>51</b>
<b>Appendix D</b>	<b>Fanout board</b>	<b>53</b>
D.1	MikroElektronika mikroBUS™ compatible connector (Fanout CN10 and CN11)	54
D.2	ESP-01 Wi-Fi board compatible connector	54
D.3	Compatible connectors for the Grove boards	55
D.3.1	Compatible connector for I <sup>2</sup> C Grove boards (Fanout CN3)	55
D.3.2	Compatible connector for UART Grove boards (Fanout CN2)	55

---

**Appendix E Federal Communications Commission (FCC)  
and Industry Canada (IC) Compliance Statements..... 56**

- E.1 FCC Compliance Statement ..... 56
  - E.1.1 Part 15.19 ..... 56
  - E.1.2 Part 15.105 ..... 56
  - E.1.3 Part 15.21 ..... 56
- E.2 IC Compliance Statement ..... 56
  - E.2.1 Compliance Statement ..... 56
- E.3 Déclaration de conformité ..... 56

**Appendix F CISPR32 ..... 57**

- F.1 Warning ..... 57

**Revision history ..... 58**

## List of tables

Table 1.	Ordering Information . . . . .	9
Table 2.	32F723EDISCOVERY board power configuration . . . . .	15
Table 3.	Control port assignment . . . . .	22
Table 4.	Wi-Fi extension connector CN14 . . . . .	23
Table 5.	GPIO assignment for Arduino pins . . . . .	24
Table 6.	GPIO assignment for PMOD pins . . . . .	25
Table 7.	PMOD: SPI or UART configuration selection . . . . .	25
Table 8.	GPIO assignment for STMod+ pins . . . . .	26
Table 9.	STMod+: SPI/UART configuration selection . . . . .	26
Table 10.	USB OTG HS Micro-AB connector CN19 . . . . .	28
Table 11.	USB OTG FS Micro-AB connector CN18 (front view) . . . . .	28
Table 12.	Pin description of the LCD Frida connector CN17 . . . . .	29
Table 13.	Pin description of the CTP connector CN16 . . . . .	30
Table 14.	USB Micro-B connector CN1 . . . . .	31
Table 15.	Audio line output connector CN5 . . . . .	32
Table 16.	Audio line input connector CN4 . . . . .	32
Table 17.	I/O assignment . . . . .	33
Table 18.	STMod+ connector signals . . . . .	52
Table 19.	Description of the mikroBUS™ connector pins . . . . .	54
Table 20.	Description of the ESP-01 Wi-Fi board connector pins . . . . .	54
Table 21.	Description of the I <sup>2</sup> C Grove board connector pins (CN3) . . . . .	55
Table 22.	Description of the UART Grove board connector pins (CN2) . . . . .	55
Table 23.	Document revision history . . . . .	58

## List of figures

Figure 1.	32F723EDISCOVERY (top view) . . . . .	1
Figure 2.	32F723EDISCOVERY (bottom view) . . . . .	1
Figure 3.	Hardware block diagram . . . . .	10
Figure 4.	32F723EDISCOVERY top layout . . . . .	11
Figure 5.	32F723EDISCOVERY bottom layout . . . . .	12
Figure 6.	32F723EDISCOVERY mechanical drawing . . . . .	13
Figure 7.	USB composite device . . . . .	14
Figure 8.	CN8 (ST-LINK) . . . . .	16
Figure 9.	CN8 (USB_STLINK) . . . . .	17
Figure 10.	CN8 (External 5V supply) . . . . .	17
Figure 11.	CN8 (USB_HS) . . . . .	18
Figure 12.	CN8 (USB_FS) . . . . .	18
Figure 13.	Wi-Fi connector CN14 (front view) . . . . .	23
Figure 14.	PMOD: Samtec SSW connector (P2) . . . . .	25
Figure 15.	STMod+: Samtec SQT connector (P1) . . . . .	26
Figure 16.	TAG connector (CN9) . . . . .	27
Figure 17.	USB OTG HS Micro-AB connector CN19 (front view) . . . . .	28
Figure 18.	USB OTG FS Micro-AB connector CN18 (front view) . . . . .	28
Figure 19.	LCD Frida connector (Hirose FH26-29S-0.3SHW) CN17 (front view) . . . . .	29
Figure 20.	CTP connector ((Hirose DF37NB-10DS-0.4V (5x)) CN16 (front view) . . . . .	30
Figure 21.	USB Micro-B connector CN1 (front view) . . . . .	31
Figure 22.	Mechanical drawing of the audio line connector . . . . .	31
Figure 23.	32F723EDISCOVERY Discovery board interconnections . . . . .	39
Figure 24.	ST-LINK/V2-1 with support of SWD . . . . .	40
Figure 25.	STM32F723IEK6 connections . . . . .	41
Figure 26.	Audio codec WOLFSON and Audio connectors . . . . .	42
Figure 27.	PSRAM . . . . .	43
Figure 28.	Quad-SPI Flash memory (MICRON) . . . . .	44
Figure 29.	Arduino Uno V3 connectors . . . . .	45
Figure 30.	USB OTG HS PHY with Micro-AB connector . . . . .	46
Figure 31.	USB OTG FS . . . . .	47
Figure 32.	LCD Frida . . . . .	48
Figure 33.	Wi-Fi, LEDs and push-buttons . . . . .	49
Figure 34.	Fanout board . . . . .	50
Figure 35.	STMod+ Fanout module plugged into P1 connector . . . . .	53

# 1 Features

- STM32F723IEK6 microcontroller featuring 512 Kbytes of Flash memory and 256 Kbytes of SRAM, in UFBGA176 package
- TFT LCD 240x240 pixels with touch panel
- USB OTG HS and FS
- SAI audio codec
- 4 ST-MEMS digital microphones
- 512-Mbit Quad-SPI Flash memory
- 8-Mbit external PSRAM
- 2 push-buttons (user and reset)
- Board connectors:
  - 2 USBs with Micro-AB
  - Stereo 3.5 mm jack for audio line input
  - Stereo 3.5 mm jack for headphone
  - Stereo speaker outputs
- Expansion connectors:
  - ESP-01 Wi-Fi® module
  - Arduino™ Uno V3
  - PMOD
  - STMod+
- Fanout board (included inside the board package) compatible with MikroElektronika Click boards, ESP-01 and Seeed Studio™ Grove modules. Provision for headers for direct breadboard plug-in
- Flexible power-supply options: ST-LINK USB  $V_{BUS}$  or external source
- On-board ST-LINK/V2-1 debugger/programmer with USB re-enumeration capability: mass storage, virtual COM port and debug port
- Comprehensive free software including a variety of examples, part of the STM32Cube package
- Support of a wide choice of integrated development environments (IDEs) including IAR™, Keil®, GCC-based IDEs

## 2 Product marking

Evaluation tools marked as "ES" or "E" are not yet qualified and therefore they are not ready to be used as reference design or in production. Any consequences deriving from such usage will not be at ST charge. In no event, ST will be liable for any customer usage of these engineering sample tools as reference design or in production.

"E" or "ES" marking examples of location:

- On the targeted STM32 that is soldered on the board (for illustration of STM32 marking, refer to the section "Package information" of the STM32 datasheet at [www.st.com](http://www.st.com)).
- Next to the evaluation tool ordering part number, that is stuck or silkscreen printed on the board

## 3 System requirements

- Windows® OS (XP, 7, 8, 10), Linux 64-bit or OS X®
- USB Type-A to Micro-B cable

## 4 Development toolchains

- Keil® MDK-ARM<sup>(a)</sup>
- IAR™ EWARM<sup>(a)</sup>
- GCC-based IDEs including free SW4STM32 from AC6

---

a. On Windows® only.



## 5 Demonstration software

The demonstration software is preloaded in the STM32F723IEK6 Flash memory. The latest versions of the demonstration source code and associated documentation can be downloaded from the [www.st.com/stm32f7-Discovery](http://www.st.com/stm32f7-Discovery) webpage.

## 6 Ordering information

To order the 32F723EDISCOVERY Discovery kit, refer to [Table 1](#).


**Table 1. Ordering Information**

Order Code	Target STM32
STM32F723E-DISCO	STM32F723IEK6

# 7 Hardware layout and configuration

The 32F723EDISCOVERY Discovery kit is designed around the STM32F723IEK6 (176-pin in UFBGA package). The hardware block diagram (see [Figure 3](#)) illustrates the connection between STM32F723IEK6 and peripherals (PSRAM, Quad-SPI Flash memory, LCD connector, USB OTG HS and FS connectors, USART, Audio, Arduino Uno V3, PMOD and STMod+ shields and embedded ST-LINK). [Figure 4](#) and [Figure 5](#) help users to locate these features on the 32F723EDISCOVERY board. The mechanical dimensions of the 32F723EDISCOVERY board are showed in [Figure 6](#).

**Figure 3. Hardware block diagram**



1. Dotted lines identify the shared signals.

## 7.1 The 32F723EDISCOVERY Discovery kit layout

Figure 4. 32F723EDISCOVERY top layout





Figure 5. 32F723EDISCOVERY bottom layout





### 7.3 Embedded ST-LINK/V2-1

The ST-LINK/V2-1 programming and debugging tool is integrated on the 32F723EDISCOVERY board. Compared to ST-LINK/V2 the changes are listed below.

The new features supported on ST-LINK/V2-1 are:

- USB software re-enumeration
- Virtual COM port interface on USB
- Mass storage interface on USB
- USB power management request for more than 100mA power on USB

These features are no more supported on ST-LINK/V2-1:

- SWIM interface
- Application voltage lower than 3V

For general information concerning the debugging and programming features that are common to both versions V2 and V2-1, refer to *ST-LINK/V2 in-circuit debugger/programmer for STM8 and STM32 User manual (UM1075)*.


#### 7.3.1 Drivers

Before connecting the 32F723EDISCOVERY board to a Windows® 7, Windows® 8 or Windows® XP PC via USB, a driver for ST-LINK/V2-1 must be installed. It can be downloaded from the [www.st.com](http://www.st.com) website.

In case the 32F723EDISCOVERY board is connected to the PC before installing the driver, the PC device manager may report some 32F723EDISCOVERY board interfaces as “Unknown”. To recover from this situation, after installing the dedicated driver, the association of “Unknown” USB devices found on the 32F723EDISCOVERY board to this dedicated driver, must be manually updated in the device manager.

*Note: It is recommended to proceed using USB Composite Device, as shown in Figure 7.*

**Figure 7. USB composite device**



### 7.3.2 ST-LINK/V2-1 firmware upgrade

The ST-LINK/V2-1 embeds a firmware upgrade mechanism for in-situ upgrade through the USB port. As the firmware may evolve during the life time of the ST-LINK/V2-1 product (for example a new functionality, bug fixes, support for new microcontroller families), it is recommended to visit the [www.st.com](http://www.st.com) website before starting to use the 32F723EDISCOVERY board and periodically, to stay up-to-date with the latest firmware version.

## 7.4 Power supply

The 32F723EDISCOVERY board is designed to be powered from a 5 V DC power source. It is possible to configure the 32F723EDISCOVERY board to use any of the sources described in the following [Table 2](#).

**Table 2. 32F723EDISCOVERY board power configuration**

CN8 configuration	Power connector	Voltage
ST-LINK	CN1	5 V
USB_STLINK	CN1	5 V
E5V	CN3	5 V
E5V	CN12	7 V-12 V => 5 V
USB_HS	CN19	5 V
USB_FS	CN18	5 V

*Note:* The Discovery board must be powered by a power supply unit or by an auxiliary equipment complying with the standard EN-60950-1: 2006+A11/2009, and must be Safety Extra Low Voltage (SELV) with limited power capability.

### 7.4.1 Supplying the board through the ST-LINK USB port (default setting)

To power the 32F723EDISCOVERY board in this way the USB host (PC) gets connected with the ST-LINK USB port through a USB Type-A to Micro-B cable

5 V DC power is provided by  $V_{BUS}$  from the USB type Micro-B connector (CN1) of ST-LINK/V2-1 (USB 5 V power source on silkscreen “ST-LINK”, see [Figure 8](#)). If the USB enumeration succeeds (as explained below), the ST-LINK 5 V link power is enabled by asserting the PWR\_ENn signal. This pin is connected to U1, a power switch ST890, which powers the board. This power switch also features a current limitation to protect the PC in case of a short-circuit on the board (current demand exceeding 700 mA).


The 32F723EDISCOVERY board can be powered from the ST-LINK USB connector CN1 (STLINK), but only the STM32F103CBT6 (U2) is powered before USB enumeration, because the host PC only provides 100 mA to the board at that time. During the USB enumeration, the 32F723EDISCOVERY board asks for the 500 mA power to the host PC. Two events can happen:

- If the host is able to provide the required power, the enumeration finishes by a “SetConfiguration” command and then, the power transistor ST890 is switched ON, the

red LED LD2 is turned ON, thus the 32F723EDISCOVERY board consumes maximum 500 mA current, but no more.

- If the host is not able to provide the requested current, the enumeration fails. Therefore the ST890 remains OFF and the STM32 part including the extension board is not powered. As a consequence the red LED LD2 remains turned OFF. In this case it is mandatory to use an external power supply.

Figure 8. CN8 (ST-LINK)



**Note:** In case the 32F723EDISCOVERY board is powered by a USB charger, there is no USB enumeration, so the led LD2 remains set to OFF permanently and the board is not powered. Only in this specific case, the resistor R5 needs to be soldered, to allow the board to be powered anyway.

The LED LD2 is lit when the 32F723EDISCOVERY board is powered by the 5 V correctly.


**Caution:** Do not connect a PC to ST-LINK (CN1) when R5 is soldered. The PC may be damaged or the board not powered correctly.

### 7.4.2 Supplying the board through a charger connected to ST-LINK

The 5 V DC power charger is connected to USB STLINK (CN1). In this case if the 32F723EDISCOVERY board is powered by an external USB charger then the debug is not available. If the PC is connected instead of the charger, then the limitation is no more effective and the PC could be damaged (5 V power source on silkscreen “USB\_STLINK” see [Figure 9](#)).




Figure 9. CN8 (USB\_STLINK)



### 7.4.3 Supplying the board from E5V (CN3 or CN12)

Figure 10. CN8 (External 5V supply)



#### From E5V: 5V DC power adapter connected to CN3

In this case, the 32F723EDISCOVERY board must be powered by a power supply unit or by an auxiliary equipment complying with standard EN-60950-1: 2006+A11/2009 connected to CN3, and must be Safety Extra Low Voltage (SELV) with limited power capability (5 V power source on silkscreen "E5V" see [Figure 10](#)).

#### From E5V: 7-12V DC power from CN12 (VIN)

7-12 V DC power supply is provided by an Arduino Uno V3 compatible shield connected to CN11, CN12, CN13 and CN15 connectors.


This 7-12 V voltage (VIN) is then converted to 5 V by a LDO (U11).

Finally, the user must fit the jumper on "E5V" position on CN8 connector, to select this LDO output (E5V) as main power supply for the board (see [Figure 10](#)).

### 7.4.4 Supplying the board from an external power supply through USB HS

A 5 V DC external power supply is connected to USB OTG HS Micro-AB connector CN19 (5 V power source on silkscreen “USB\_HS”, refer to [Figure 11](#)).


Figure 11. CN8 (USB\_HS)



### 7.4.5 Supplying the board from an external power supply through USB FS

A 5 V DC external power supply is connected to USB OTG FS Micro-AB connector CN18 (5 V power source on silkscreen “USB\_FS”, see [Figure 12](#)).

Figure 12. CN8 (USB\_FS)



## 7.5 Programming/debugging when the power supply is not from ST-LINK

It is mandatory to power the board first using CN3 (E5V) or CN12 (VIN) or CN18 (USB FS) or CN19 (USB\_HS), then connecting the USB cable to the PC. Proceeding this way ensures that the enumeration succeeds thanks to the external power source.

The following power sequence procedure must be respected:

1. Connect the jumper CN8 on (E5V) or (USB\_HS) or (USB\_FS)
2. Connect the external power source to CN3 or CN12 or CN18 or CN19
3. Check that the red LED LD2 is turned ON
4. Connect the PC to USB connector CN1

If this order is not respected, the 32F723EDISCOVERY Discovery board may be powered by  $V_{BUS}$  first from ST-LINK and the following risks may be encountered:

1. If more than 500 mA current is needed by the board, the PC may be damaged or current can be limited by PC. As a consequence the board is not powered correctly.
2. 500 mA is requested at the enumeration: if the PC cannot provide such current, there is a risk that the request is rejected and the enumeration does not succeed.

## 7.6 Clock sources

Up to 2 clock sources as described below:

- X2, 25 MHz oscillator for STM32F723IEK6 microcontroller.
- X3, 32 KHz crystal for STM32F723IEK6 embedded RTC

## 7.7 Reset sources

The reset signal of the 32F723EDISCOVERY board is active low and the reset sources include:

- Reset button B2
- Arduino Uno V3 shield board from CN12
- Embedded ST-LINK/V2-1

## 7.8 Audio

An audio codec WM8994ECS/R from CIRRUS with 4 DACs and 2ADCs is connected to SAI interface of STM32F723IEK6. It communicates with STM32F723IEK6 via I<sup>2</sup>C bus:

- The analog line input is connected to ADC of WM8994ECS/R through blue audio jack CN4
- The analog line output is connected to DAC of WM8994ECS/R via green audio jack CN5
- Two external speakers can be connected to WM8994ECS/R via CN10 for left speaker and CN7 for right speaker
- Four digital microphones (ST-MEMS microphone) MP34DT01TR are on 32F723EDISCOVERY board. They are connected to input digital microphones of WM8994ECS/R

## 7.9 USB OTG HS

The 32F723EDISCOVERY board supports USB OTG high-speed communication via a USB Micro-AB connector.

A USB power switch is also connected on  $V_{BUS}$  and provides power to CN19. The green LED LD8 is lit in one of these cases:

- Power switch is ON and 32F723EDISCOVERY board works as a USB host
- $V_{BUS}$  is powered by another USB host when 32F723EDISCOVERY board works as a USB device.

The red LED LD7 is lit when an overcurrent occurs.

*Note:1* When the 32F723EDISCOVERY board is powered by the ST-LINK then the OTG function can provide up to 100 mA.

*Note:2* When the 32F723EDISCOVERY board is powered by an external power supply then the OTG function can provide more than 100 mA, according to the external power supply capability.

*Note:3* When the 32F723EDISCOVERY board is powered by an external power supply through USB HS connector (CN19), in device mode, do not use a PC as power source (see [Section 7.4.4.](#))

## 7.10 USB OTG FS

The 32F723EDISCOVERY board supports USB OTG full speed communication via a USB Micro-AB connector.

A USB power switch is also connected on  $V_{BUS}$  and provides power to CN18. The green LED LD9 is lit in one of these cases:

- Power switch is ON and the 32F723EDISCOVERY board works as a USB host
- $V_{BUS}$  is powered by another USB host when the 32F723EDISCOVERY board works as a USB device.

The red LED LD10 is lit when an overcurrent occurs.

*Note:1* When the 32F723EDISCOVERY board is powered by the ST-LINK then the OTG function provides up to 100 mA.

*Note:2* When the 32F723EDISCOVERY board is powered by an external power supply then the OTG function provides more than 100 mA, according to the external power supply capability.

*Note:3* When the 32F723EDISCOVERY board is powered by an external power supply through USB FS connector (CN18), in device mode, do not use a PC as power source (see [Section 7.4.5](#))

*Note:4* On "Rev.C" boards (MB1260 C01), for device mode, the path in ESD protection U22 from USB data pins causes a raised voltage on USB  $V_{BUS}$  after disconnection. As a result the device disconnect event is not detected and so BCD capability cannot be used.

*Note:5* On "Rev.D" boards (MB1260 D01), no more limitation: device disconnect event is detected and BCD capability can be used.

## 7.11 PSRAM memory

An 8-Mbit PSRAM (IS66WV51216EBLL-55BLI from Integrated Silicon Solution Inc) is connected to the FMC interface of the STM32F723IEK6 with 16 bits of data and 18 bits of addresses (4-Mbit memory accessible).

## 7.12 Quad-SPI NOR Flash memory

A 512-Mbit Quad-SPI NOR Flash memory (MX25L51245G from MACRONIX) is connected to Quad-SPI interface of STM32F723IEK6.

## 7.13 Virtual COM port

The serial interface USART6 is directly available as a virtual COM port of the PC connected to the ST-LINK/V2-1 USB connector CN1. The virtual COM port settings are configured as: 115200 b/s, 8 bits data, no parity, 1 stop bit, no flow control.

## 7.14 TFT LCD 240x240 pixels

A 240x240-pixel TFT LCD (FRD154BP2902 from Frida) is connected to FMC data interface of STM32F723IEK6.

It uses the Sitronix ST7789H2 controller for 262K-color, TFT-LCD graphic type. Display data are stored in the on-chip display data RAM of 240x320x18 bits. It performs display data RAM read/write operation with no external operation clock to minimize power consumption.

External PSRAM can also be used to store display data.

LCD\_RS signal is used to determine whether bus is carrying data or control/command registers.

## 7.15 Capacitive Control Touch panel

Capacitive Control Touch Panel (Frida LS015GF614A) is controlled by STM32F723IEK6 through I<sup>2</sup>C.

## 7.16 Buttons and LEDs

The black button B2 located LCD side is the reset of the microcontroller STM32F723IEK6.

The blue button B1 located LCD side is available to be used as a digital input or as alternate function wake-up. When the button is pressed the logic state is 1, otherwise the logic state is 0.

Three LEDs located on the LCD side are available for the user. The LEDs are LD1 Arduino (blue), LD5 User 1 (red) and LD6 User 2 (green). To light a LED a low-logic state 0 should be written in the corresponding GPIO.

[Table 3](#) gives the assignment of control ports to the LED indicators.

Table 3. Control port assignment

Reference	Color	Name	Comment
B1	BLUE	USER	Alternate function Wake-up
B2	BLACK	RESET	-
LD1	BLUE	ARDUINO	PA5
LD2	RED	5 V Power	-
LD3	RED	Fault Power	Current upper than 625 mA
LD4	RED/GREEN	ST-LINK COM	Green during communication
LD5	RED	USER1	PA7
LD6	GREEN	USER2	PB1
LD7	RED	USB OTG HS OVCR	PH10
LD8	GREEN	V <sub>BUS</sub> USB HS	PB13
LD9	RED	USB OTG FS OVCR	PB10
LD10	GREEN	V <sub>BUS</sub> USB FS	PA9

## 8 Connectors

### 8.1 Wi-Fi ESP-01 compatible connector

Figure 13. Wi-Fi connector CN14 (front view)




Table 4. Wi-Fi extension connector CN14

Pin number	Wi-Fi description
1	WIFI_RX
2	3.3 V
3	GPIO0
4	WIFI-RST
5	GPIO2
6	CH_PD
7	GND
8	WIFI_TX

### 8.2 Arduino Uno V3 compatible connectors

CN11, CN12, CN13 and CN15 are female connectors compatible with Arduino Uno V3 standard. Most shields designed for Arduino Uno V3 are also supported by the 32F723EDISCOVERY board.

The Arduino connectors on 32F723EDISCOVERY board support the Arduino Uno V3.

**Caution:** The I/Os of STM32 microcontroller are 3.3 V compatible instead of 5 V for Arduino Uno V3.

Table 5. GPIO assignment for Arduino pins

I/O	Name	Pin number		Name	I/O
-	-	-	CN11.10	SCL2	PH4 <sup>(1)</sup>
-	-	-	CN11.9	SDA2	PH5 <sup>(1)</sup>
-	-	-	CN11.8	V <sub>REF+</sub>	-
-	-	-	CN11.7	GND	-
-	NC	CN12.1	CN11.6	SCK1	PA5
-	3.3 V	CN12.2	CN11.5	MISO1	PB4
-	NRST	CN12.3	CN11.4	MOSI1	PB5
-	3.3 V	CN12.4	CN11.3	NSS1	PA1
-	5 V	CN12.5	CN11.2	TIM12_CH1	PH6
-	GND	CN12.6	CN11.1	GPIO	PE4
-	GND	CN12.7	-	-	-
-	V <sub>IN</sub>	CN12.8	CN13.8	GPIO	PE3
-	-	-	CN13.7	TIM9_CH2	PE6
PA6	ADC1_IN6	CN15.1	CN13.6	TIM3_CH3 <sup>(2)</sup>	PB0
PA4	ADC1_IN4	CN15.2	CN13.5	GPIO	PH3
PC4 <sup>(2)</sup>	ADC1_IN14	CN15.3	CN13.4	TIM9_CH1	PE5
PF10	ADC3_IN8	CN15.4	CN13.3	GPIO	PC5
PC0	ADC1_IN10	CN15.5	CN13.2	TX2	PA2
PC1	ADC1_IN11	CN15.6	CN13.1	RX2	PA3

1. Shared between Arduino and STMod+.

2. Exclusive use: Arduino or STMod+.

### 8.3 PMOD and STMod+ connectors P2 and P1

On the 32F723EDISCOVERY board, PMOD and STMod+ connectors are providing flexibility in small form factor applications.

Based on existing PMOD Digilent standard popular in connectivity, the 32F723EDISCOVERY board is supporting the PMOD type 2A and 4A on P2 connector.

STMod+ P1 connector uses PMOD signals with extended SPI and spare I/Os for different peripheral expansion. The related STM32F723IEK6 I/Os for PMOD and STMod+ function are listed in [Table 18: STMod+ connector signals](#).

Refer to [Section Appendix C: PMOD and STMod+ schematic table](#) to find more information about PMOD and STMod+ pins. Refer to [Section Appendix D: Fanout board](#) to find more information about STMod+ compatible Fanout board.

The user must select the different configurations using PMOD\_SEL\_0 (PH15) and PMOD\_SEL\_1 (PI10) to control the STG3692QTR (U20). This quad analog S.P.D.T. (Single Pole Dual Throw) allows to connect PMOD and STMod+: either to UART or to SPI or to both in case of STMod+.



### 8.3.1 PMOD connector P2

PMOD connector is 2x6 pins with 2.54 mm pitch and right-angle female connector. Samtec SSW-106-02-F-D-RA is selected for PMOD connector (second source is available: ATOM FH254206C-1600).

Figure 14. PMOD: Samtec SSW connector (P2)




Table 6. GPIO assignment for PMOD pins

I/O	Name	Pin number		Name	I/O
PI0 / PF9	NSS2 / CTS7	1	7	INT	PB11
PI3 / PF7	MOSI2p / TX7	2	8	RESET	PF11
PI2 / PF6	MISO2p / RX7	3	9	GPIO0	PG12
PI1 / PF8	SCK2 / RTS7	4	10	GPIO1	PH2
	GND	5	11	GND	
	3.3 V	6	12	3.3 V	

Table 7. PMOD: SPI or UART configuration selection

Pin name	PMOD SPI	PMOD UART
PMOD_SEL_0 (PH15)	0	1
PMOD_SEL_1 (PI10)	0	1
PMOD#1	NSS	CTS
PMOD#2	MOSIp	TX
PMOD#3	MISOp	RX
PMOD#4	SCK	RTS

Refer to [Section Appendix C: PMOD and STMod+ schematic table](#) to find more information about PMOD pins.

### 8.3.2 STMod+ connector P1

STMod+ connector is 2x10 pins with 2.0 mm pitch and right angle female connector. Samtec SQT-110-01-F-D-RA is selected for STMod+ connector (second source: ATOM FH200210C-12000).

Figure 15. STMod+: Samtec SQT connector (P1)




Table 8. GPIO assignment for STMod+ pins

I/O	Name	Pin number		Name	I/O
PI0 / PF9	NSS2 / CTS7	1	11	INT	PB11
PI3 / PF7	MOSI2p / TX7	2	12	RESET	PF11
PI2 / PF6	MISO2p / RX7	3	13	ADC1_IN14	PC4 <sup>(1)</sup>
PI1 / PF8	SCK2 / RTS7	4	14	TIM3_CH3	PB0 <sup>(1)</sup>
-	GND	5	15	5 V	-
-	5 V	6	16	GND	-
PH4 <sup>(2)</sup>	SCL2	7	17	TX4p	PH13
PC3	MOSI2s	8	18	RX4p	PH14
PC2	MISO2s	9	19	PWM	PA15
PH5 <sup>(2)</sup>	SDA2	10	20	RX4s	PC11

1. Exclusive use: Arduino or STMod+.

2. Shared between Arduino and STMod+.

Table 9. STMod+: SPI/UART configuration selection

Pin name	STMod+ SPI	STMod+ UART	STMod+ UART and SPI <sup>(1)</sup>
PMOD_SEL_0 (PH15)	0	1	1
PMOD_SEL_1 (PI10)	0	1	0
PMOD#1	NSS	CTS	NSS
PMOD#2	MOSIp	TX	TX

Table 9. STMod+: SPI/UART configuration selection (continued)

Pin name	STMod+ SPI	STMod+ UART	STMod+ UART and SPI <sup>(1)</sup>
PMOD#3	MISOp	RX	RX
PMOD#4	SCK	RTS	SCK
STMod+#8	N/A	N/A	MOSIs
STMod+#9	N/A	N/A	MISOs

1. Default configuration.


Refer to [Section Appendix C: PMOD and STMod+ schematic table](#) to find more information about STMod+ signals available on P1 connector. Refer to [Section Appendix D: Fanout board](#) to find more information about STMod+ compatible Fanout board.

## 8.4 TAG connector CN9

TAG connector is a 10-pin footprint supporting SWD mode, which shares same signals with ST-LINK: PA13 (JTMS / SWDIO), PA14 (JTCLK / SWCLK), PB3 (JTDO / SWO), PB4 (NRST).

TC2050-IDC-NL cable is used to link ST-LINK and TAG connector, so users can easily program and debug the STM32 without using any extra accessory.

Figure 16. TAG connector (CN9)



## 8.5 USB OTG HS Micro-AB connector

Figure 17. USB OTG HS Micro-AB connector CN19 (front view)




Table 10. USB OTG HS Micro-AB connector CN19

Pin number	Description	Pin number	Description
1	$V_{BUS}$	4	ID
2	D-	5	GND
3	D+	-	-

Note: *STMP5 U13 is providing  $V_{BUS}$ . It is active high, controlled by PH12. Overcurrent is sent to PH10 interrupt.*

## 8.6 USB OTG FS Micro-AB connector

Figure 18. USB OTG FS Micro-AB connector CN18 (front view)




Table 11. USB OTG FS Micro-AB connector CN18 (front view)

Pin number	Description	Pin number	Description
1	$V_{BUS}$	4	ID
2	D-	5	GND
3	D+	-	-

Note: *STMP5 U14 is providing  $V_{BUS}$ . It is active low, controlled by PG8. Overcurrent is sent to PB10 interrupt.*

## 8.7 LCD Frida connector

Figure 19. LCD Frida connector (Hirose FH26-29S-0.3SHW) CN17 (front view)




Table 12. Pin description of the LCD Frida connector CN17

Pin number	Description	Pin connection	Pin number	Description	Pin connection
1	GND	GND	2	FMARK	PC8 (TE INT)
3	DB15	FMC_D15	4	DB14	FMC_D14
5	DB13	FMC_D13	6	DB12	FMC_D12
7	DB11	FMC_D11	8	DB10	FMC_D10
9	DB9	FMC_D9	10	DB8	FMC_D8
11	DB7	FMC_D7	12	DB6	FMC_D6
13	DB5	FMC_D5	14	DB4	FMC_D4
15	DB3	FMC_D3	16	DB2	FMC_D2
17	DB1	FMC_D1	18	DB0	FMC_D0
19	NRD	FMC_NOE	20	NWR	FMC_NWE
21	RS	PF0 (FMC_A0)	22	NCS	PG9 (NE)
23	RESET	PH7 (LCD_RST)	24	IM	VDD
25	IOVCC	VDD	26	VCI	3.3 V
27	GND	GND	28	LEDA	LEDA
29	LEDK	LEDK	-	-	-

Note: LEDA and LEDK backlight is controlled by STLD40DPUR (U12) with PH11 PWM.

## 8.8 Control Touch Panel (CTP) Frida connector

Figure 20. CTP connector ((Hirose DF37NB-10DS-0.4V (5x) CN16 (front view)




Table 13. Pin description of the CTP connector CN16

Pin number	Description
1	GND
2	INT
3	GND
4	SDA
5	SCL
6	GND
7	RESET
8	IOVCC
9	VDD
10	GND

### 8.9 ST-LINK/V2-1 USB Micro-B connector CN1

The USB connector CN1 is used to connect embedded ST-LINK/V2-1 to PC for programming and debugging of STM32F723IEK6 microcontroller.

Figure 21. USB Micro-B connector CN1 (front view)




Table 14. USB Micro-B connector CN1


Pin number	Description	Pin number	Description
1	V <sub>BUS</sub> (power)	4	GND
2	DM	5, 6	Shield
3	DP	-	-

### 8.10 Audio stereo speakers

The stereo audio outputs CN10 and CN7 are available to support stereo speakers (left and right respectively).

### 8.11 Audio line connectors

Figure 22. Mechanical drawing of the audio line connector



### 8.11.1 Audio line output (green jack) connector

A 3.5 mm stereo audio green jack output CN5 is available to support the headphone (see [Figure 22](#)).

**Table 15. Audio line output connector CN5**

Pin number	Description
3	GND
4	Right
6	Left

### 8.11.2 Audio line input (blue jack) connector

A 3.5 mm stereo audio blue jack input CN4 is available to support the audio line input (see [Figure 22](#)).

**Table 16. Audio line input connector CN4**

Pin number	Description
3	GND
4	Right
6	Left



## Appendix A 32F723EDISCOVERY Discovery board I/O assignment

Table 17. I/O assignment

Pin number	Pin	Function	Label
A1	PE3	GPIO_Output	ARD_D7_GPIO
A2	PE2	QUADSPI_BK1_IO2	-
A3	PE1	FMC_NBL1	-
A4	PE0	FMC_NBL0	-
A5	PB8	I2C1_SCL	-
A6	PB5	SPI1_MOSI	ARD_D11_TIM3_CH2_SPI1_MOSI
A7	PG14	GPIO_Output	WIFI_RST
A8	PG13	GPIO_Output	WIFI_GPIO_0
A9	PB4	SPI1_MISO	ARD_D12_SPI1_MISO
A10	PB3	SYS_JTDO-SWO	-
A11	PD7	FMC_NE1	-
A12	PC12	UART5_TX	UART_TXD_WIFI_RX
A13	PA15	TIM2_CH1	STMOD+_TIM2_CH1_2_ETR
A14	PA14	SYS_JTCK-SWCLK	-
A15	PA13	SYS_JTMS-SWDIO	-
B1	PE4	GPIO_Output	ARD_D8_GPIO
B2	PE5	TIM9_CH1	ARD_D3_TIM9_CH1
B3	PE6	TIM9_CH2	ARD_D6_TIM9_CH2
B4	PB9	I2C1_SDA	-
B5	PB7	FMC_NL	-
B6	PB6	QUADSPI_BK1_NCS	-
B7	PG15	GPIO_EXTI15	SAI2_INT
B8	PG12	GPIO_Output	PMOD_GPIO_0
B10	PG10	SAI2_SD_B	-
B11	PD6	GPIO_Output	WIFI_GPIO_2
B12	PD0	FMC_D2	-
B13	PC11	GPIO_Output	STMOD+_UART4_RXD_s
B14	PC10	QUADSPI_BK1_IO1	-
B15	PA12	USB_OTG_FS_DP	-
C2	PI7	SAI2_FS_A	-
C3	PI6	SAI2_SD_A	-

Table 17. I/O assignment (continued)

Pin number	Pin	Function	Label
C4	PI5	SAI2_SCK_A	-
C10	PG9	FMC_NE2	-
C11	PD5	FMC_NWE	-
C12	PD1	FMC_D3	-
C13	PI3	GPIO_Output	PMOD_SPI2_MOSI
C14	PI2	GPIO_Output	PMOD_SPI2_MISO
C15	PA11	USB_OTG_FS_DM	-
D3	PI9	GPIO_EXTI9	CTP_INT
D4	PI4	SAI2_MCLK_A	-
D10	PD4	FMC_NOE	-
D11	PD3	GPIO_Output	WIFI_CH_PD
D12	PD2	UART5_RX	UART_RXD_WIFI_TX
D13	PH15	GPIO_Output	PMOD_SEL_0
D14	PI1	SPI2_SCK	PMOD_SPI2_SCK
D15	PA10	GPIO_Output	USB_OTG_FS_ID
E1	PC14-OSC32_IN	RCC_OSC32_IN	-
E2	PF0	FMC_A0	-
E3	PI10	GPIO_Output	-
E12	PH13	UART4_TX	STMOD+_UART4_TXD
E13	PH14	UART4_RX	STMOD+_UART4_RXD
E14	PI0	SPI2_NSS	PMOD_SPI2_NSS
E15	PA9	USB_OTG_FS_VBUS	-
F1	PC15-OSC32_OUT	RCC_OSC32_OUT	-
F4	PH2	GPIO_Output	PMOD_GPIO_1
F14	PC9	QUADSPI_BK1_IO0	-
F15	PA8	I2C3_SCL	-
G1	PH0-OSC_IN	RCC_OSC_IN	-
G4	PH3	GPIO_Output	ARD_D4_GPIO
G14	PC8	GPIO_EXTI8	LCD_TE_INT
G15	PC7	USART6_RX	-
H1	PH1-OSC_OUT	RCC_OSC_OUT	-
H2	PF2	FMC_A2	-
H3	PF1	FMC_A1	-
H4	PH4	I2C2_SCL	ARD_D15_STMOD+_I2C2_SCL <sup>(1)</sup>

Table 17. I/O assignment (continued)

Pin number	Pin	Function	Label
H14	PG8	GPIO_Output	USB_OTGFS_PPWR_EN
H15	PC6	USART6_TX	-
J2	PF3	FMC_A3	-
J3	PF4	FMC_A4	-
J4	PH5	I2C2_SDA	ARD_D14_STMOD+_I2C2_SDA <sup>(1)</sup>
K1	PF7	UART7_TX	PMOD_UART7_TXD
K2	PF6	UART7_RX	PMOD_UART7_RXD
K3	PF5	FMC_A5	-
K12	PH12	GPIO_Output	USB_OTGHS_PPWR_EN
K13	PG5	FMC_A15	-
K14	PG4	FMC_A14	-
K15	PG3	FMC_A13	-
L1	PF10	ADC3_IN8	ARD_A3_ADC3_IN8
L2	PF9	UART7_CTS	PMOD_UART7_CTS
L3	PF8	UART7_RTS	PMOD_UART7_RTS
L12	PH11	TIM5_CH2	-
L13	PH10	GPIO_Input	USB_OTGHS_OVCR_INT
L14	PD15	FMC_D1	-
L15	PG2	FMC_A12	-
M2	PC0	ADC2_IN10	-
M3	PC1	ADC2_IN11	-
M4	PC2	SPI2_MISO	STMOD+_SPI2_MISOs
M5	PC3	SPI2_MOSI	STMOD+_SPI2_MOSIs
M6	PB2	QUADSPI_CLK	-
M7	PG1	FMC_A11	-
M11	PH6	TIM12_CH1	ARD_D9_TIM12_CH1
M12	PH8	I2C3_SDA	-
M13	PH9	GPIO_Output	CTP_RST
M14	PD14	FMC_D0	-
M15	PD13	QUADSPI_BK1_IO3	-
N2	PA1	TIM2_CH2	ARD_D10_TIM2_CH2_SPI1_NSS
N3	PA0-WKUP	SYS_WKUP1	-
N4	PA4	ADC2_IN4	ARD_A1_STMOD+_ADC_DAC <sup>(2)</sup>
N5	PC4	ADC2_IN14	ARD_A2_ADC

Table 17. I/O assignment (continued)

Pin number	Pin	Function	Label
N6	PF13	FMC_A7	-
N7	PG0	FMC_A10	-
N11	PE13	FMC_D10	-
N12	PH7	GPIO_Output	LCD_RST
N13	PD12	FMC_A17	-
N14	PD11	FMC_A16	-
N15	PD10	FMC_D15	-
P2	PA2	USART2_TX	ARD_D1_USART2_TX
P3	PA6	ADC2_IN6	-
P4	PA5	SPI1_SCK	ARD_D13_SPI1_SCK
P5	PC5	GPIO_Output	ARD_D2_GPIO
P6	PF12	FMC_A6	-
P7	PF15	FMC_A9	-
P8	PE8	FMC_D5	-
P9	PE9	FMC_D6	-
P10	PE11	FMC_D8	-
P11	PE14	FMC_D11	-
P12	PB12	GPIO_Output	USB_OTG_HS_ID
P13	PB13	GPIO_EXTI13	USB_OTG_HS_VBUS
P14	PD9	FMC_D14	-
P15	PD8	FMC_D13	-
R2	PA3	USART2_RX	ARD_D0_USART2_RX
R3	PA7	GPIO_Output	SYS_LD_USER1
R4	PB1	GPIO_Output	SYS_LD_USER2
R5	PB0	TIM3_CH3	ARD_D5_STMOD+_TIM3_CH3 <sup>(2)</sup>
R6	PF11	GPIO_Input	PMOD_RESET
R7	PF14	FMC_A8	-
R8	PE7	FMC_D4	-
R9	PE10	FMC_D7	-
R10	PE12	FMC_D9	-
R11	PE15	FMC_D12	-
R12	PB10	GPIO_EXTI10	USB_OTGFS_OVCR_INT
R13	PB11	GPIO_EXTI11	PMOD_INT

Table 17. I/O assignment (continued)

Pin number	Pin	Function	Label
R14	PB14	USB_OTG_HS_DM	-
R15	PB15	USB_OTG_HS_DP	-

1. Shared between Arduino and STMod+.
2. Exclusive use: Arduino or STMod+.

## Appendix B Electrical schematics

This section provides design schematics of the features for the 32F723EDISCOVERY Discovery board and Fanout boards:

- MB1260 (32F723EDISCOVERY Discovery board)
  - 32F723EDISCOVERY Discovery board interconnexion ([Figure 23](#))
  - ST-LINK/V2-1 with support of SWD only ([Figure 24](#))
  - STM32F723IEK6 connections ([Figure 25](#))
  - Audio codec WOLFSON and Audio connectors ([Figure 26](#))
  - PSRAM ([Figure 27](#))
  - Quad-SPI Flash memory (MICRON) ([Figure 28](#))
  - Arduino Uno V3 connectors ([Figure 29](#))
  - USB OTG HS PHY with Micro-AB connector ([Figure 30](#))
  - USB OTG FS ([Figure 31](#))
  - LCD Frida ([Figure 32](#))
  - Wi-Fi, LEDs and push-buttons ([Figure 33](#))
- MB1280 (Fanout board)
  - Fanout board ([Figure 34](#))



**Figure 23. 32F723EDISCOVERY Discovery board interconnections**




Figure 24. ST-LINK/V2-1 with support of SWD



Title: ST-LINK/V2-1 with support of SWD only			
Project: STM32F723e-DISCO			
Size: A4	Reference: MB1260	Revision: D-01	life.automated
Date: 21/12/2016	Sheet: 2 of 12		




**Figure 25. STM32F723IEK6 connections**




Figure 26. Audio codec WOLFSON and Audio connectors




Figure 27. PSRAM






Figure 28. Quad-SPI Flash memory (MICRON)





Figure 29. Arduino Uno V3 connectors




Title: <b>Arduino UNO connectors</b>		
Project: <b>STM32F723e-DISCO</b>		
Size: A4	Reference: MB1260	Revision: D-01
Date: 19/12/2016	Sheet: 7 of 12	





Figure 30. USB OTG HS PHY with Micro-AB connector





**Figure 31. USB OTG FS**




Figure 32. LCD Frida







**Figure 33. Wi-Fi, LEDs and push-buttons**




Figure 34. Fanout board



## Appendix C PMOD and STMod+ schematic table

The [Table 18](#) gives the description of the signals available on the STMod+ connector. It also shows which signal is shared with other board connectors (such as PMOD or Arduino Uno V3). A switch controlled by software is present to select which function is used (using PI10 and PH15 PIOs). Analog signals are in brackets [xxx]. The I<sup>2</sup>C bus is shared with the Arduino Uno V3 connectors. It is recommended to check the device slave address when adding it to the bus. Refer to the following list of acronyms before reading the [Table 18](#):

- RTS7 stands for USART7\_RTS
- ADC2.4 stands for ADC\_2\_IN4
- T8.4 stands for TIM\_8\_CH4
- MOSI5 stands for SPI\_5\_MOSI



Table 18. STMod+ connector signals

-	-	-	STMod+							-	-	-	
ARD	PMOD	Some other AF	Basic	SW	Pin	Pin number		Pin	N/A	Basic	Some other AF	PMOD	ARD
-	CTS	MOSI5/[ADC3.7]/T14.1	CTS7	PI10=1	PF9	1	11	PB11	-	INT	SDA2/RX3/T2.4	INT	-
	NSS	T5.4	NSS2	PI10=0	PI0								
-	TX	SCK5/[ADC3.5]/T11.1	TX7	PH15=1	PF7	2	12	PF11	-	RST	MOSI5	RST	-
	MOSI	T8.8ETR	MOSI2p	PH15=0	PI3								
-	RX	NSS5/[ADC3.4]/T10.1	RX7	PH15=1	PF6	3	13	PA4	-	ADC/DAC <sup>(1)</sup>	NSS1/NSS3/CK2/[ADC2.4]/ [DACOUT1.1]	GPIO (PG12)	ADC <sup>(1)</sup>
	MISO	T8.4	MISO2p	PH15=0	PI2								
-	RTS	MISO5/[ADC3.6]/T13.1	RTS7	PI10=1	PF8	4	14	PB0	-	PWM <sup>(1)</sup>	CTS4/[ADC1.8]/[ADC2.8]/ T1.2N/T3.3/T8.2N	GPIO (PH2)	PWM <sup>(1)</sup>
	SCK	T8.BKIN2	SCK2	PI10=0	PI1								
-	-	-	GND	-	GND	5	15	+5 V	-	+5 V	-	-	-
-	-	-	+5 V	-	+5 V	6	16	GND	-	GND	-	-	-
SCL2 <sup>(2)</sup>	-	-	SCL2 <sup>(2)</sup>	-	PH4	7	17	PH13	-	GPIO	TX4/TXCAN1/T8.1N	-	-
-	-	[ADC1.13]/[ADC2.13]/[ADC3.13]	MOSI2s	-	PC3	8	18	PH14	-	GPIO	RX4/RXCAN1/T8.2N	-	-
-	-	[ADC1.12]/[ADC2.12]/[ADC3.12]	MISO2s	-	PC2	9	19	PA15	-	GPIO	NSS1/NSS3/RTS4/T2.1/T2. 2_ETR	-	-
SDA2 <sup>(2)</sup>	-	NSS5	SDA2 <sup>(2)</sup>	-	PH5	10	20	PC11	-	GPIO	MISO3/RX3/RX4	-	-

1. Exclusive use: Arduino or STMod+.
2. Shared between Arduino and STMod+.

## Appendix D Fanout board


The Fanout board (see [Figure 35](#)) comes with the 32F723EDISCOVERY Discovery board.

It is connected to STMod+ connector (P1) and it provides access to:

- MikroElektronika Click board compatible connectors (CN10 and CN11: two 1x8-pin female connectors)
- ESP-01 compatible connector (CN4: 2x4-pin female connector)
- Seed Studio™ Grove compatible connectors (CN3 and CN2: two 1x4-pin male connectors)
- Reserved standard 2.54 mm pitch of STMod+ pin header for breadboard.

The main active component for this Fanout board is the 3.3 V regulator U1 (200 mA).

**Figure 35. STMod+ Fanout module plugged into P1 connector**



## D.1 MikroElektronika mikroBUS™ compatible connector (Fanout CN10 and CN11)

The mikroBUS™ compatible connector is 2.54" pitch with a pair of 1x8-pin female connectors. [Table 19](#) below shows the definition of the pins.

**Table 19. Description of the mikroBUS™ connector pins**

STMod+ connector CN11 number	Function of mikroBUS	Pin number	Pin number	Function of mikroBUS	STMod+ connector CN10 number
STMod+#13-ADC <sup>(1)</sup>	AN	1	1	PWM	STMod+#14-PWM <sup>(1)</sup>
STMod+#12-RST	RST	2	2	INT	STMod+#11-INT
STMod+#1-NSS	CS	3	3	RX	STMod+#3-RX
STMod+#4-SCK	SCK	4	4	TX	STMod+#2-TX
STMod+#9-MISOs	MISO	5	5	SCL	STMod+#7-SCL <sup>(2)</sup>
STMod+#8-MOSIs	MOSI	6	6	SDA	STMod+#10-SDA <sup>(2)</sup>
-	+3.3 V	7	7	+5 V	-
-	GND	8	8	GND	-

1. Exclusive use: Arduino or STMod+.

2. Shared with Arduino.

The mikroBUS™ pinout assignment is available at the: <http://mikroe.com> website.

## D.2 ESP-01 Wi-Fi board compatible connector

The ESP-01 Wi-Fi board connector is 2.54 pitch with 2x4-pin female connectors. [Table 20](#) shows the definition of the pins.

**Table 20. Description of the ESP-01 Wi-Fi board connector pins**

STMod+ connector number	Function of ESP-01	Pin number	Pin number	Function of ESP-01	STMod+ connector number
-	GND	1	8	TXD	STMod+#3-RX
STMod+#14	GPIO2	2	7	CH_PD	STMod+#13
STMod+#11	GPIO0	3	6	RST	STMod+#12-RST
STMod+#2-TX	RXD	4	5	V <sub>CC</sub>	-

## D.3 Compatible connectors for the Grove boards

The two connectors of the Grove board are 2.54 pitch with 1x4-pin male connectors, the part number is 1125S-SMT-4P.

### D.3.1 Compatible connector for I<sup>2</sup>C Grove boards (Fanout CN3)

The CN3 connector is compatible with Grove- Barometer sensor (BMP180) and Grove-LCD RGB Backlight boards using cable for connection. [Table 21](#) shows the definition of the pins.

**Table 21. Description of the I<sup>2</sup>C Grove board connector pins (CN3)**

STMod+ connector	Function of Grove CN3	PIN number
STMod+#7-SCL (*)	SCL	1
STMod+#10-SDA (*)	SDA	2
+5 V	VCC	3
-	GND	4

### D.3.2 Compatible connector for UART Grove boards (Fanout CN2)

The CN2 connector is compatible with Grove-NFC boards using cable for connection. [Table 22](#) shows the definition of the pins

**Table 22. Description of the UART Grove board connector pins (CN2)**

STMod+ connector	Function of Grove CN2	Pin number
STMod+#3-RX	RX (Grove TX)	1
STMod+#2-TX	TX (Grove RX)	2
+5 V	VCC	3
-	GND	4

## **Appendix E Federal Communications Commission (FCC) and Industry Canada (IC) Compliance Statements**

### **E.1 FCC Compliance Statement**

#### **E.1.1 Part 15.19**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **E.1.2 Part 15.105**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### **E.1.3 Part 15.21**

Any changes or modifications to this equipment not expressly approved by STMicroelectronics may cause harmful interference and void the user's authority to operate this equipment.

### **E.2 IC Compliance Statement**

#### **E.2.1 Compliance Statement**

Industry Canada ICES-003 Compliance Label: CAN ICES-3 (A)/NMB-3(A).

### **E.3 Déclaration de conformité**

Étiquette de conformité à la NMB-003 d'Industrie Canada : CAN ICES-3 (A)/NMB-3(A).



## Appendix F CISPR32

### F.1 Warning

Warning: This device is compliant with Class A of CISPR32. In a residential environment, this equipment may cause radio interference.

## Revision history

**Table 23. Document revision history**

Date	Revision	Changes
10-Feb-2017	1	Initial release.
28-Apr-2017	2	Updated <a href="#">Section Appendix B: Electrical schematics</a> .

**IMPORTANT NOTICE – PLEASE READ CAREFULLY**

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2017 STMicroelectronics – All rights reserved