


## Lesson 2: Tutorial Of The Buzzer



### Key Points

As a basic electronic component that generates sound. We always encounter Buzzers in life, whether it's in the computer, the alarm clock, or the printer, the scanner, and the alarm, etc. It is widely used, and its usage is extremely simple. In this section, we will learn some relevant knowledge of the buzzer.

Key points:

1. Finish the programming of the buzzer to get different tones.
2. Get familiar to the programming for Arduino and some relative functions
3. Equipment needed: USB cable, miniQ .

### Buzzer on your car

The car has a passive buzzer, it is a bit difficult to use, but the tone is freely under control, so it is a worthwhile. The buzzer can be used for playing simple music which improved the performance of the car. That may be very interesting. Now let's download a sample code of buzzer to have a try:

- Open the file “buzzer.ino” under the folder “buzzer” :

```

song | Arduino 1.0.4
File Edit Sketch Tools Help

song
#define QUARTER 0.25
#define EIGHTH 0.25
#define SIXTEENTH 0.625

int tune[]= //list the frequency with Numbered music
{
    NTD3, NTD3, NTD4, NTD5,
    NTD5, NTD4, NTD3, NTD2,
    NTD1, NTD1, NTD2, NTD3,
    NTD3, NTD2, NTD2,
    NTD3, NTD3, NTD4, NTD5,
    NTD5, NTD4, NTD3, NTD2,
    NTD1, NTD1, NTD2, NTD3,
    NTD2, NTD1, NTD1,
    NTD2, NTD2, NTD3, NTD1,
    NTD2, NTD3, NTD4, NTD3, NTD1,
    NTD2, NTD3, NTD4, NTD3, NTD2,
    NTD1, NTD2, NTD5, NTD0,
    NTD3, NTD3, NTD4, NTD5,
}

Done compiling.
o:\Print.cpp:44: warning: '__progmem__' attribute ignored
C:\arduino-1.0.4-windows\arduino-1.0.4\hardware\tools\avr\bin\avr-g+
+ -c -g -Os -Wall -fno-exceptions -ffunction-sections
-fdata-sections -mmcu=atmega32u4 -DF_CPU=16000000L -MMD
23
Arduino Leonardo on COM44

```

### 1. the code of buzzer

- Use the USB cable to connect the car with the computer, turn on the power of the car, then click the “download” button to flash the code into car. When the downloading is finished, you can hear two different types of tones.
- If you feel the performance is simple, then you can download the “song.ino” under the “song” folder, then you can hear a simple song, much better than the tones. At the same time you can learn from the code about how to control buzzer frequency and maybe you should master the “for” statements.

## Code analysis

- ✧ Define “BUZZER” as pin 16 which attach to buzzer
  - `#define BUZZER 16`
- ✧ In initial function we initialize the pin to OUTPUT state
  - `void setup() //initial function`
  - `{`

- `pinMode(BUZZER,OUTPUT);//initialize the pin to OUTPUT`
  - `}`
- ✧ The codes to play tones
- `for(i=0;i<80;i++)`
  - `{`
  - `digitalWrite(BUZZER,HIGH);//set pin 16 to 5V(HIGH)`
  - `delay(1); // delay 1ms`
  - `digitalWrite(BUZZER,LOW);//set pin 16 to 0V(LOW)`
  - `delay(1); //delay 1ms`
  - `}`

## Knowledge about Buzzers

Buzzer is an integrated component which uses the DC power supply, and is widely used in computers, printers, photocopiers, alarms, electronic toys, automotive electronic equipment, telephones, timers and other electronic products as voice devices.

Buzzers can be divided into passive buzzer and active buzzer.

The active buzzer is directly connected to the rated power (new buzzers have labels on the top) and once the power is in, it rings; while passive buzzers are as the same as electromagnetic speakers, need to be connected to the voice source in the audio output circuit.

Note: The "source" here does not mean power, but to oscillation source which means an active buzzer has an oscillation source inside, so as long as the power is on, it works; and a passive buzzer doesn't have an internal oscillation source, so if use DC power indirectly, it can't ring. We must use 2k - 5KHZ square wave to drive it. Active buzzer is often more expensive than the passive, because the oscillation circuit inside.

The advantages of passive buzzer;


1. Cheaper
2. The sound frequency can be controlled as acoustic spectrum
3. In some special cases, it can reuse pins with LED

The advantage of active buzzer;

1. Convenient


## Circuit parts

The drive part of the circuit is shown in the figure below, Q1 is a transistor, U1 is the buzzer, R1 is a resistor, and D16 is Arduino digital No.14 pin.



2. Buzzer circuit

This is a visual figure of the circuit diagram above:



3. Buzzer connection diagram

In figure 3, the current from the positive polar pass through the resistance and buzzer, then disconnect on the triode, because normally the triode is cut off, so the buzzer is not working. When the chip controlled the triode on, the triode will allow

current to pass, we just need the current pass or not by a frequency, the buzzer will ring. Of course, because the way we setup the connection diagram, the triode can only accept 0V or 5V signal, the current passed the buzzer is equal to the chip to the power of the cathode current multiplied by the magnification of the triode.

## Enrich Yourself

After the study of how to use a buzzer, it is not enough if you just let the buzzer sing few times, in the outclass study, you can use a buzzer hint if a button is pressed, the car's speed, environmental temperature and humidity condition. And also use it in temperature alarm, over-speed alarm, or the obstacles ahead alarm, etc.

Next class will also learn the use of photoresistance, and then we can make good use of the buzzer.

## Continue

Since we have studied something about buzzer, let us learn about other device usage and function below:

1. The triode: the full name should be semiconductor triode, also known as triode transistor, is a kind of component whose current is controlled by current, its does the amplification work to change weak signal into radial value larger electrical signals, also used as a non-contact switch.

Since the chip can only provide small current, if this small current is used to make buzzer working, the volume will be small or unable to be heard. In the car, the solution is to attach the buzzer to a triode, just control the triode switch pin. In this way, the chip could control the triode then indirect control the buzzer.

2. Resistance:

In physics we call the inhibition of electric current "resistance", this sounds blurry. The role of resistance in circuit: the famous Ohm's law can be used to control voltage and current in the circuit resistance. In the image above, R1 is an resistance, the function is to limit the current in the circuit. So now that we

have already used the triode amplifier current why resistance for limiting current is needed? First we explain why we want to limit the current, we know that buzzer has its own power rating (power needed for normal work), if more than rated power use for a long time, the buzzer will be damaged fast, a simple example is to give the old flashlight bulb double voltage instead the voltage it needed previous, the light bulb will soon be destroyed. Let's look back above the circuit, if D16 pin gave a high voltage, the transistor Q1 should be conducted, the circuit flow from the positive (VCC) to the negative (GND) terminal, if there is no resistor (R1), the current in the circuit will be very big, because there is nearly zero resistance (the resistance is very small, just buzzer and triode itself), the volume will be very loud (could be considered beyond the rated power). As a result, you can see that R1 played a protective role in the circuit. Part of its function is to control the buzzer volume, control noise in order to not affect other people, after all, we are delighted of controlling buzzers when others perhaps in meditation or exercises on programming, it is also the key point where we should note in the study.